

# TSC

Technical Systems Consultants  
Box 2574 W. Lafayette IN 47906

# TSC

## MICRO BASIC PLUS

COPYRIGHT 1976 by  
Technical Systems Consultants

### I. INTRODUCTION:

This version of BASIC is a subset of the statements and commands usually available on large machines. The purpose of this manual is not to teach BASIC but simply to demonstrate the syntax and sample usage of MICRO BASIC PLUS. Particular attention should be paid to Appendix C which shows how to adapt this program to your particular system.

As in all TSC software, a great effort has been put forth in testing to eliminate "bugs" in the code. This however is no guarantee of perfect code. If a suspected bug is spotted, please jot down the circumstances involved and send it to us. We will do our best to send out errata sheets with all patches to owners of MICRO BASIC PLUS if necessary.

### II. GENERAL INFORMATION:

- A. The initial starting address is hex 0100. To restart after returning to monitor program, address hex 0103 should be used. This is set up automatically If MIKBUG is being used.
- B. The prompt character is "!".
- C. Line numbers must be between 0 and 9999 (4 digits maximum). Imbedded spaces are not permitted.

- D. Numbers in arithmetic expressions must be between -99999 and +99999. If a larger number is entered, the least significant 5 digits are the only ones used.
- E. Spaces are not permitted internal to numbers or keywords but may be used freely elsewhere.
- F. All keywords (PRINT, GOTO, etc.) must be followed by a space or non alphabetic character.
- G. Expressions are evaluated left to right with all operator precedence being equal. Parenthesis should be used to group sub-expressions. The allowed operators are +, -, \*, /, and ^. There are several functions available also. ^ is used for exponentiation.
- H. Variables are the 26 letters "A" through "Z". Variables may be DIMENSIONED either single (maximum = 98) or double (maximum = 98 x 98).
- I. Multiple statements per line are permitted using a ":" as the separator.
- J. Calculator mode of operation is permitted by typing a statement without a line number. MICRO BASIC PLUS will immediately perform the operation. Example:

```
PRINT 4*7
```

will print the answer 28 and then return with the prompt.

### III. EDITING FEATURES:

- A. Lines may be entered in any sequence. The interpreter automatically puts them in ascending order. It is recommended that multiples of 10 be used so if insertions are necessary they can be easily done.
- B. Line numbers should begin in column 1.
- C. To delete an existing line simply type that line number followed by a carriage return.
- D. Backspacing is done using "control H".
- E. To delete the current line being entered, type "control X".
- F. Lines may be inserted, deleted, or added at anytime.
- G. Line lengths are limited to 72 characters. If this is exceeded the line entered is thrown away and a new prompt will be issued.

### IV. COMMANDS:

- A. SCRATCH is used to delete the current users program from memory as well as clear all variables. Normally used without a line number but may appear in program with suicidal results.
- B. RUN is used to start executing the users program with the lowest numbered line. May be used with a line number as well.
- C. MONITOR is used to return to your monitor system.
- D. LIST is used to list the users program. Several forms exist:
  - 1. LIST c.r. - Lists the entire program
  - 2. LIST X c.r. - Lists line X.
  - 3. LIST X, Y c.r. - Lists Y lines starting at line X.
  - 4. LIST X, c.r. - Lists entire program starting at line X.

- E. BREAK: The "BREAK" key is used any time a BASIC program is running or a program is being listed and you wish it to stop. Hitting the "BREAK" key will cause current operation to halt and the prompt to be issued.

## V. ASSIGNMENT STATEMENTS:

### A. LET

1. Form:

LET (variable) = (expression)

2. Examples:

10 LET A = 200

20 LET B = C\*62

3. The word "LET" is optional.

Example:

30 D = 25 + A/B

### B. READ and DATA

1. DATA statements contain a list of expressions or constants separated by commas and must be entered all on the same line. Each DATA statement "executed" becomes the current DATA statement, thus allowing several different DATA statements throughout the program.
2. READ is used to assign variables the values in a DATA statement. The first READ causes the first value of the current DATA statement to be assigned to the variable of the READ statement. The second READ gets the second value, etc.

3. If all data of the current DATA statement has been read, the next READ statement will go back and read the first value of that DATA statement.

4. Example:

```
10 DATA 2, 10, 12, -65/3, 42 + A
```

```
20 READ X, Y, Z
```

this results in  $X = 2$ ,  $Y = 10$ ,  $Z = 12$ . The next READ would cause the value of  $-65/3$  to be assigned.

#### C. RESTORE

1. Used in conjunction with READ and DATA statements. When a RESTORE statement is executed, it causes the "pointer" which is pointing to the next piece of data in a DATA statement to move (be restored) to the first value of that data statement. May be thought of as restoring the "pointer" to its original position.

2. Example:

```
DATA 2, 4, 6, 8
```

```
READ X, Y
```

```
RESTOR
```

```
READ A
```

This results in  $X = 2$ ,  $Y = 4$  and  $A = 2$  due to the RESTOR statement.

#### D. INPUT

1. The INPUT statement allows data entry during program execution.
2. Form:

```
INPUT "(optional string)", (variable), (variable)
```

3. The string portion of INPUT will type out the string on the terminal before issuing the prompt.
4. The INPUT prompt is a question mark, signifying BASIC is ready to accept input.
5. As many strings and variables may be used on one INPUT as desired.
6. If more than one value is to be input after the "?", the values should be separated by a comma.
7. The number of values entered must exactly equal the number of variables of the INPUT statement. If too few are entered another "?" will be output. If too many are entered, the excess will be ignored.
8. After the last value is Input, a "carriage return" should be entered. This terminates the input.
9. Only constants may be entered.
10. If a mistake is made on an entry a "control X" may be typed to delete that particular entry and a "?" will be output. This can only be done before the comma or carriage return is entered and only deletes the last value entered.
11. Examples:

```
10 INPUT A
```

```
20 INPUT "NUMBER", X
```

```
30 INPUT B, C, D
```

When line 20 is executed, the word NUMBER will be printed on the terminal followed by a "?". If 25 is then typed, X will be assigned the value 25.

12. The INPUT statement may also be used to stop the program but not ask for any values.

Example:

```
50 INPUT "STOP"
```

This causes STOP to be printed, no "?" will be issued. To restart execution, a carriage return must be entered.

## VI. OUTPUT STATEMENT

### A. PRINT

1. Form:

```
PRINT (list)
```

2. The (list) may be a list of variables, constants, or expressions in which case these values will be output to the terminal.
3. The (list) may also contain strings of alphanumeric characters enclosed in quotes ("). In this case the string would be output to the terminal.
4. The (list) may be blank in which case a blank line will be output, (skip a line).
5. Formatting Output:
  - a. There are 9 print zones available per line, each being 8 columns wide.
  - b. To make use of the print zones, items in the print list should be followed by a comma. When this is done, the next item to be printed will start in the next available zone. If 2 successive commas are used, a print zone will be skipped. If an alphanumeric string is output and extends into part of a following zone, the comma will

cause the next printed item to start in the next unoccupied zone.

- c. Semicolons may be used instead of commas. The semicolon does not cause the next item to be in the next available zone but instead it will be printed in the next available column (no spacing).
- d. Two output formatting functions are also permitted, TAB and SPC. See function description for their use.

6. Examples:

```
10 PRINT "THE ANSWER IS"; A
20 PRINT "X = "; X, "Y = ";Y
30 PRINT A, B, C,, D
40 PRINT 2*(R+S), 62*4, A
```

## VII. SUBSCRIPTED VARIABLES:

### A. GENERAL INFORMATION

- 1. Subscripted variables should be thought of as arrays, vectors, matrices, or a variable with several values (memory locations).
- 2. All arrays may be either one or two dimensions.
- 3. The lowest subscript value is 0.
- 4. The maximum value is 98.

### B. DIMENSION statement.

- 1. All subscripted variables must first appear in a DIMENSION statement. (DIM). It is good practice to put all DIM statements at the start of the program.



2. DIM is used to set the maximum **size** of an array.
3. Only constants can be used in DIM statements.
4. Examples:

```
10 DIM A(8), B(6,6)
```

```
20 DIM X(20,4)
```

```
30 DIM X(5), Y(10), Z(98)
```

5. When using subscripted variables they should have the form:

X(expression) or X(expression, expression)

where X is the variable and the expression can be any valid expression including other subscripted variables. If the value of the subscript exceeds the value for which that variable was DIMENSIONED, an error will result.

Examples:

```
A(3)
```

```
B(6+R, S(16))
```

```
Z(5, A(B))
```

## VIII. TRANSFER OF CONTROL STATEMENTS

### A. GOTO

1. Form:

GOTO (line no.)

2. The line number may be represented as a variable, constant, or expression.
3. GOTO causes transfer of control to the line specified.

4. If used on multiple statements per line it should be the last statement.

5. Examples:

```
10 GOTO 100
```

```
20 GOTO 200 + B
```

#### B. GOSUB

1. Form:

```
GOSUB (line no.)
```

2. The line number may be represented as a variable, constant, or expression.
3. If used on multiple statements per line it should be the last statement.

4. Examples:

```
35 GOSUB 200
```

```
40 GOSUB 102 + B
```

5. Subroutines may be nested as deep as the stack will permit.

#### C. RETURN

1. Used to return from a subroutine
2. Returns to next line numbered statement following the calling GOSUB.

#### D. ON statement

1. Used with GOTO or GOSUB
2. Forms:

```
ON (expression) GOTO (expression), ..., (expression)
```

```
ON (expression) GOSUB(expression), ..., (expression)
```

3. The value of the expression after ON is used to determine which of the expressions following the GO- should be evaluated to form the destination line number. The first expression is selected on a value of 1, the second for 2, etc.
4. The maximum number of expressions is 9.
5. If the value is less than 1 or greater than the number of expressions provided, the last one listed will be used.
6. Examples:

ON A GOTO 100, 200, 300

If A = 1 control will be transferred to line 100; if A = 2, 200, etc.

## IX. CONDITIONAL STATEMENT

### A. IF-THEN

1. Form:

IF X1 OP X2 THEN ST

where X1 and X2 can be constants, variables, or expressions and ST is any MICRO BASIC PLUS statement. OP is a comparison operator (see below).

2. Transfer of control is conditional depending on the result of the comparison of X1 and X2. If the comparison is true, the statement following the THEN is executed. If the comparison is false, the statement following the THEN is ignored.
3. THEN is optional.

4. Comparison operators are the following:

<u>SYMBOL</u>	<u>EXAMPLE</u>	<u>MEANING</u>
=	A=B	A equals B
<	A<B	A is less than B
>	A>B	A is greater than B
<=	A<=B	A is less than or equal to B
>=	A>=B	A is greater than or equal to B
<>	A<>B	A is not equal to B

5. Examples:

```

10 IF A<B THEN PRINT "YES"

15 IF 2*C <= D+5 LET C = 5

20 IF A<B IF C<D PRINT "NO"

25 IF 12>X + (2*A) THEN 200

```

The last example is used to GOTO line 200 (GOTO is not needed).

## X. PROGRAM LOOPS

### A. FOR and NEXT

1. Form:

```
FOR C = C1 TO C2 STEP C3
```

where C is the control or index variable, C1 is its initial value, C2 is its final value, and C3 is the increment size.

2. The index variable can not be a DIMENSIONED variable.

3. STEP is optional and if left off the value of C3 is assumed to be +1.

4. STEP may be positive for forward counting or negative for backwards counting.
5. All FOR-NEXT loops are executed at least once.
6. Loops may be nested as deep as memory will permit.
7. While nesting loops, no index variable should be used more than once.
8. Loops may be exited at any time.
9. Loops may be reentered if not previously indexed out.
10. NEXT is used to close the loops and should state the index variable of that loop.
11. Examples:

```
10 FOR A = 1 TO 10  
  
20 NEXT A  
  
50 FOR I = D*2 TO 100 + 3 STEP 2  
  
60 NEXT I
```

12. If expressions are used for C1, C2, and C3, they will be evaluated each time through the loop.

## XI. MISCELLANEOUS STATEMENTS

### A. REMARK

1. Used to insert remarks into programs.
2. Skipped during execution.
3. Example:

```
10 REMARK TEST 1  
  
20 REM THIS IS A REMARK.
```

## B. END

1. Used to terminate a MICRO BASIC PLUS program.

## C. EXTERNAL

2. Used to execute machine code subroutines.
3. See Appendix D for details of its use.

## XII. FUNCTIONS:

## A. ARITHMETIC FUNCTIONS

1. SGN has the form:

$$\text{SGN}(X)$$

where X may be any arithmetic expression. This function returns a value of +1 for positive arguments, 0 if X is zero, and -1 for negative arguments.

2. ABS returns the absolute value of its argument. It has the form:

$$\text{ABS}(X)$$

where X is any expression

3. RND should be treated as a variable rather than a function since it has no argument. Whenever RND appears in an expression it will be replaced by a random number between 0 and 99.

4. Examples:

$$\text{LET } A = \text{SGN}(100-B)$$

$$B = \text{ABS}(R*100/C)$$

$$R = 65 + \text{RND}$$

## B. OUTPUT FORMATTING FUNCTIONS.

1. TAB is used to move to a desired print column. It has the form:

$$\text{TAB}(X)$$

where X can be any expression. If the value of the argument is less than or equal to the column presently in, the TAB will be ignored.

2. SPC is used to output a specified number of spaces. It has the form:

SPC (X)

where X is any expression.

3. Examples:

10 PRINT TAB(6); A

prints the value of A starting in column 6.

20 PRINT X; SPC(5); Y

prints 5 spaces between the values of X and Y.

30 PRINT TAB(A+B); "\*"; SPC(10); X

#### XIII. OTHER INFORMATION:

- A. All keywords may be written using the first 3 letters.  
(PRINT = PRI, INPUT = INP, etc.)
- B. Some syntax checking is performed by MICRO BASIC PLUS during initial line entry.
- C. When using the exponentiation operator (^) only 2 digits are allowed for the exponent (largest exponent is 99).

- D. Keep in mind that large dimensioned variables eat up memory quickly. For example, to dimension A as A(98, 98) requires 29405 bytes of storage! To determine the amount of memory used, use the following formula:

$$\text{Number of bytes} = 3 * ((\text{1st dimension} + 1) * (\text{2nd dimension} + 1)) + 2$$



## APPENDIX A

## ERROR CODES FOR MICRO BASIC PLUS

<u>ERROR NUMBER</u>	<u>MEANING</u>
10	Unrecognizable keyword
14	Illegal variable
16	No line number referenced by GOTO or GOSUB
20	Expression syntax, unbalanced parens, or dimension error
21	Expression expected but not found
22	Divided by zero
23	Arithmetic overflow
24	Expression too complex
31	Syntax error in PRINT statement
32	Missing closing quote in printed string
40	Bad DIM statement
45	Syntax error in INPUT statement
51	Syntax error in READ statement
62	Syntax error in IF statement
73	RETURN with no GOSUB
81	Error with FOR-NEXT
90	Memory overflow
99	"BREAK" detected

## APPENDIX B

## DUMPING AND LOADING PROCEDURES

## I. DUMPING THE PROGRAM

After entering your MICRO BASIC PLUS program it is usually desirable to dump it to paper or cassette tape. If using Motorola's MIKBUG the procedure is extremely simple. First, from BASIC, enter the command MON to return to the monitor. MICRO BASIC PLUS has already done all the work of setting the punch limits. All that is necessary once in MIKBUG is to type "P" after turning on your recording device. For other systems, see Appendix C.

## II. LOADING THE PROGRAM

While in MICRO BASIC PLUS type MON to return to MIKBUG. Prepare to load your cassette or paper tape as usual. Type "L" (MIKBUG's load function). When complete, type "G" and BASIC will return with the prompt. A quick LIST will verify your load. MICRO BASIC PLUS should always be reentered at location hex 103 to avoid clearing memory.

## APPENDIX C

## ADAPTING MICRO BASIC PLUS

I. This section is primarily intended for those who own systems not based around Motorola's MIKBUG, and hopefully gives enough information for adaptation. MICRO BASIC PLUS has been assembled for MIKBUG systems containing 8K of memory. If a different amount is available (as little as 4K may be used) the "memory end" should be adjusted accordingly as stated in part 11 below. (If EXT will not be used and a 4K system is owned, set memory end (locations 010F - 0110) to 0F and FF respectively).

II. MEMORY END is stored in locations 010F and 0110. It is now set to 1EFF which requires an 8K system. If your system is of different size, this number should be adjusted accordingly. BASIC will not run correctly if this is not set up for your system. Space should also be allowed for a stack (= 128 BYTES) + any I/O patches if MIKBUG is not being used.

III. BREAK is presently referenced at location 010C. It jumps to an internal break routine at location 0452. This routine monitors MIKBUG's PIA for activity such that hitting the "BREAK" key during program execution or listing will immediately return to the main BASIC loop and respond with the prompt.

If using an ACIA this could be written to look for a special character, for example control C, before kicking out.

- IV. OUTEEE is a jump to the output routine in MIKBUG (character in accumulator A, other registers undisturbed), and is at location 0106. If MIKBUG is not used, this should be patched to vector to your routine.
- V. INCH is a jump to the input routine in MIKBUG and is at location 0109. Patch this if a different routine is used.
- VI. COLD START should be done from location 0100 hex. Warm start is automatically setup and stored in MIKBUG's P.C. (A048 and A049). This is set up at location 01B3.
- VII. STACK is initialized at 0186 and its top is set to A07F in MIKBUG's RAM. If different stroage is allocated for the stack, allow at least 128 BYTES. \*IMPORTANT - at location 0943 the bottom of the stack is referenced. If the stack is moved this reference should be changed accordingly!
- VIII. PUNCH LIMIT for dumping the source are set up in MICRO BASIC PLUS at locations 01C3 and 01C8., If MIKBUG is not used, these should be changed accordingly.
- IX. PROMPT CHARACTER is stored at location 01D4. This may be changed if desired.
- X. BACKSPACE CODE is stored at location 02D4. This may be changed.
- XI. CANCEL CODE is at locations 02E3 and 07C2. These may be changed if both are changed identically.
- XII. MON returns to MIKBUG. If a different monitor is used, the entry address at location 015F should be changed to that of the monitor used.

## XIII. MEMORY ASSIGNMENT

0000-0003	Random number locations (must not all be 00)
00B0-00FD	Undimensioned variable storage
0100	START entry point
0103	RESTART entry point
0106	JUMP to OUTPUT CHARACTER
0109	JUMP to INPUT CHARACTER
010C	JUMP to BREAK routine
010F-0110	MEMORY END pointer
015F-0160	Monitor program entry point address
01B7-01B8	Stack address
01C3-01C4	Low punch limit address
01C8-01C9	High punch limit address
01D4	Prompt character (!)
02D4	Backspace code (control-H)
02E3	Line cancel code (control-X)
07C2	Line cancel code (control-X)
0D4D-0D4E	Pointer to end of user's source program
0D4F	Start of users source program
0FFF	Actual end of memory (4K system)
1EFF	Suggested MEMORY END (8K system)
1F00	Suggested EXT address (8K system)
1FFF	Actual end of memory (8K system)

## For MIKBUG users:

A000	Stack end
A002-A003	Low punch limit
A004-A005	High punch limit
A048-A049	MIKBUG PC
A07F	Stack beginning
E0E3	MIKBUG entry point
E1AC	INPUT routine
E1D1	OUTPUT routine

## APPENDIX D

## THE EXTERNAL STATEMENT

The EXTERNAL (EXT) statement is internally set up to do a "JSR" to location 1F00. This can be found in BASIC at location 0701 and should be changed according to memory organization used. It is important that all EXT routines exist beyond the address set up as the end of memory.

At first glance EXT seems limiting since only one address can be jumped to. This is not the case however. All non dimensioned variables are stored in fixed locations requiring three bytes each starting at location 00B0. (A = 0080, B = 0083, C = 00B6, etc.). They are stored as packed BCD with the least significant digits in the highest address (L.S.D. of A are in 0082). With this in mind, a variable can be chosen as a reference such that upon execution of EXT that variable can be read from memory and used as an offset or index in a "jump table". Using this method, one can have many, program selected, EXTERNAL routines available. All EXTERNAL routines should end with an "RTS". Be sure to adjust "memory end" as required if using this feature of MICRO BASIC PLUS.

## APPENDIX E

## INSTRUCTION SUMMARY

<u>COMMANDS</u>	<u>STATEMENTS</u>	<u>FUNCTIONS</u>
RUN	LET	GOTO
LIST	READ	GOSUB
SCRATCH	DATA	ON-GOTO
MONITOR	RESTORE	ON_GOSUB
BREAK	INPUT	RETURN
	PRINT	FOR
	REM	NEXT
	END	IF-THEN
	DIM	EXTERNAL

MATH OPERATORS

- (unary) Minus  
 - (unary) Plus  
 \* Multiplication  
 / Division  
 ^ Exponentiation  
 + Addition  
 - Subtraction

RELATIONAL OPERATORS

= Equal  
 < Less than  
 > Greater than  
 <= Less than or equal  
 >= Greater than or equal  
 <> Not equal

Line Numbers - 0 to 9999

Constants - 99999 to +99999

Variables - single letters, A to Z, may be subscripted

Backspace - control H

Line cancel - control X

## APPENDIX F

## SAMPLE PROGRAMS

```

10 REM BASIC PLUS 'SWITCH'
12 REM THE OBJECT OF SWITCH IS TO REARRANGE A
14 REM RANDOM SEQUENCE TO NUMERICAL ORDER, LEFT TO RIGHT.
16 REM THIS IS DONE BY 'SWITCH'ING A PARTIAL
18 REM SEQUENCE STARTING FROM THE LEFT. FOR EXAMPLE
20 REM SWITCH 3 WOULD REVERSE THE SEQUENCE OF THE FIRST
22 REM THREE NUMBERS FROM THE LEFT.
25 DIM M(9)
30 FOR I=1 TO 9 : M(I)=10-I : NEXT I
40 FOR I=1 TO 10
50 A=RND/12+1
60 K=M(A) : M(A)=M(1) : M(1)=K
70 NEXT I
80 PRINT "THE SEQUENCE IS ":T=0
90 GOSUB 220
100 INPUT "      SWITCH HOW MANY ",D
110 IF D>0 IF D<10 GOTO 120
115 GOTO 100
120 E=1:T=T+1
130 IF D<=E GOTO 150
140 F=M(E):M(E)=M(D):M(D)=F : D=D-1 : E=E+1 : GOTO 130
150 FOR I=1 TO 9
160 IF M(I)<>I GOTO 90
170 NEXT I
175 GOSUB 220
180 PRI:PRINT "YOU WIN IN ";T;" MOVES"
190 PRI:INPUT "WANT TO PLAY AGAIN (YES=1) ",T
200 IF T=1 GOTO 30
210 END
220 FOR I=1 TO 9:PRI M(I);:NEXT I:RET

```



```

!
!LIST
10 REM TEST OF RANDOM NUMBER DISTRIBUTION
15 DIM X(9)
20 GOSUB 1000
30 INPUT *NUMBER OF TIMES ",A
40 FOR B=0 TO 9: X(B)=0: NEXT B
50 FOR B=1 TO ABS(A)
60 C=RND/10: X(C)=X(C)+1
70 NEXT B
80 GOSUB 1000
90 PRINT TAB(10); "NUMBER"; TAB(20); "TIMES"
100 PRINT TAB(10); "-----"; TAB(20); "-----": PRI
110 FOR I=0 TO 9: PRI TAB(12); I; TAB(21); X(I)
120 NEXT I
130 GOSUB 1000
135 R=0
140 FOR J=0 TO 9: R=R+(J*X(J)): NEXT J
150 PRINT "AVERAGE = "; R/A; " "; R-(R/A*A)
155 Z=2
160 IF R/A<4 LET Z=1
170 IF R/A>4 THEN Z=3
180 GOSUB 1000
190 ON Z GOSUB 300,400,500
200 END
300 PRINT "AVERAGE IS LOW": RETURN
400 PRI "AVERAGE IS OK!!": RET 500 PRIN *AVERAGE IS HIGH": RET
1000 PRI: PRI: RET

```

| RUN

NUMBER OF TIMES ? 1000

NUMBER TIMES

0	101
1	97
2	110
3	102
4	93
5	96
6	100
7	103
8	97
9	101

AVERAGE = 4.481

AVERAGE IS OK!!

!

\* MICRO BASIC PLUS SOURCE LISTING  
 \*  
 \* MICRO BASIC PLUS  
 \* COPYRIGHT (C) 1976 BY  
 \*  
 \* TECHNICAL SYSTEMS CONSULTANTS  
 \* BOX 2574  
 \* W. LAFAYETTE INDIANA 47906  
 \*  
 \*

## \* EQUATES

A07F	STACK	EQU	\$A07F
8004	PIAADR	EQU	\$8004
A002	PFILBG	EQU	\$A002
A004	PFILEN	EQU	\$A004
1F00	EXTERN	EQU	\$1F00
E0E3	MONITR	EQU	\$E0E3
A048	MONPC	EQU	\$A048
A000	STKBOT	EQU	\$A000

## \* TEMPORARY STORAGE

0000	RNDM	RMB	4
0004	BUFPNT	RMB	2
0006	FORSTK	RMB	2
0008	DIMPNT	RMB	2
000A	XTEMP3	RMB	2
000C	DATAST	RMB	2
000E	DATAPT	RMB	2
0010	TRYVAL	RMB	2
0012	CRFLAG	RMB	1
0013	QMFLAG	RMB	1
0014	ROWVAR	RMB	1
0015	ROWCON	RMB	1
0016	COLCON	RMB	1
0017	TABFLG	RMB	1
0018	DIMFLG	RMB	1
0019	RUNFLG	RMB	1
001A	DATAFL	RMB	1
001B	SUBCNT	RMB	1
001C	LETFLG	RMB	1
001D	FLDCNT	RMB	1
001E	NXPNTR	RMB	2
0020	XTEMP	RMB	2
0022	XSAVE	RMB	2
0024	XSAVE2	RMB	2
0026	NUMCNT	RMB	1
0027	NEGFLG	RMB	1
0028	NOEXFL	RMB	1
0029	EXTRA	RMB	2
002B	COUNT	RMB	1
002C	STKCNT	RMB	1
002D	AUXCNT	RMB	1
002E	SIGN	RMB	1
002F	AXSIGN	RMB	1
0030	OVFLBF	RMB	1
0031	XTEMP2	RMB	2
0033	XTEMP4	RMB	2
0035	XTEMP5	RMB	2
0037	CPX1	RMB	2
0039	CPX2	RMB	2
003B	STKEND	RMB	3
003E	CHRCNT	RMB	1
003F	OPSTAK	RMB	32
005F	AC	RMB	3
0062	NUMBER	RMB	3
0065	AX	RMB	3

```

0068          BUFFER   RMB      72

          *  LABEL TABLE

00B0          LBLTBL   RMB      78
00FE          STKTOP   RMB      2

          *  CONSTANTS

0008          BACKSP   EQU      $8
0018          DELCOD   EQU     $18
0021          PRMPTC   EQU     $21

0100                      ORG    $0100

          *  MAIN PROGRAM

0100 7E 01 A6  START    JMP      MICBAS      JMP TO BEGIN
0103 7E 01 B0  RESTRT   JMP      FILBUF

          *  EXTERNAL I-O ROUTINES

0106 7E E1 D1  OUTEEEE  JMP      $E1D1
0109 BD E1 AC  INCH     JSR      $E1AC
010C 7E 04 52  BREAK    JMP      INTBRK
010F 1E FF     MEMEND   FDB      $1EFF

          *  KEYWORD AND JUMP TABLE

0111 50          KEYTBL  FCC      ;PRI;
0112 52 49
0114 04 A6          FDB      PRINT

0116 49          FCC      ;INP;
0117 4E 50
0119 07 98          FDB      INPUT

011B 49          FCC      ;IF ;
011C 46 20
011E 08 B2          FDB      IF

0120 4C          FCC      ;LET;
0121 45 54
0123 07 72  LETADR  FDB      LET

0125 46          FCC      ;FOR;
0126 4F 52
0128 09 76          FDB      FOR

012A 4E          FCC      ;NEX;
012B 45 58
012D 09 9D          FDB      NEXT

012F 47          FCC      ;GOT;
0130 4F 54
0132 07 81          FDB      GOTO

0134 47          FCC      ;GOS;
0135 4F 53
0137 09 2B          FDB      GOSUB

0139 4F          FCC      ;ON ;
013A 4E 20
013C 08 76          FDB      ONGOTO

013E 52          FCC      ;RET;
013F 45 54
0141 09 53          FDB      RETURN

```

0143 52	FCC	;REA;
0144 45 41		
0146 08 26	FDB	READ
0148 44	FCC	;DAT;
0149 41 54		
014B 08 17	FDB	DATA
014D 52	FCC	;RES;
014E 45 53		
0150 08 6C	FDB	RESTOR
0152 44	FCC	;DIM;
0153 49 4D		
0155 06 71	FDB	DIM
0157 45	FCC	;EXT;
0158 58 54		
015A 07 01	FDB	EXTRNL
015C 4D	FCC	;MON;
015D 4F 4E		
015F E0 E3	FDB	MONITR
0161 45	FCC	;END;
0162 4E 44		
0164 01 B0	FDB	FILBUF
0166 52	FCC	;REM;
0167 45 4D		
0169 07 04	FDB	RUNEXC
016B 52	FCC	;RUN;
016C 55 4E		
016E 07 5F	FDB	RUN
0170 4C	FCC	;LIS;
0171 49 53		
0173 03 EC	FDB	LIST
0175 53	FCC	;SCR;
0176 43 52		
0178 01 A6	FDB	MICBAS
017A 00	FCB	0
017B 52	FCTTBL FCC	;RND;
017C 4E 44		
017E 0A C0	FDB	EVAL88
0180 41	FCC	;ABS;
0181 42 53		
0183 0A BC	FDB	EVAL85
0185 53	FCC	;SGN;
0186 47 4E		
0188 0A B4	FDB	EVAL86
018A 00	FCB	0

## \* INITIALIZATION

018B CE 01 00	CLRBEG	LDX	#START	
018E DF 0A		STX	XTEMP3	SAVE X
0190 CE 00 0C	CLRBG2	LDX	#DATAST	SET START
0193 20 08		BRA	CLEAR	GO CLEAR
0195 FE 01 0F	CLREND	LDX	MEMEND	SET END
0198 DF 0A		STX	XTEMP3	SAVE

019A	FE	0D	4D		LDX	ENDSTR	
019D	4F			CLEAR	CLR A		CLEAR ACC.
019E	A7	00		CLEAR2	STA A	0,X	CLEAR BYTE
01A0	08				INX		BUMP THE POINTER
01A1	9C	0A			CPX	XTEMP3	DONE?
01A3	26	F9			BNE	CLEAR2	
01A5	39				RTS		RETURN
01A6	8D	E3		MICBAS	BSR	CLRBEG	GO CLEAR
01A8	CE	0D	4F		LDX	#STORSP	
01AB	FF	0D	4D		STX	ENDSTR	SET END STORAGE:
01AE	8D	E5			BSR	CLREND	GO CLEAR

## \* GET LINE INTO INPUT BUFFER

01B0	CE	01	03	FILBUF	LDX	#RESTRT	
01B3	FF	A0	48		STX	MONPC	SET UP RETURN POINTER
01B6	8E	A0	7F		LDS	#STACK	
01B9	CE	00	68		LDX	#BUFFER	
01BC	DF	0A			STX	XTEMP3	SAVE BOUND
01BE	8D	D0			BSR	CLRBG2	
01C0	CE	0D	4D		LDX	#ENDSTR	SET PUHCH LIMITS
01C3	FF	A0	02		STX	PFILBG	
01C6	EE	00			LDX	0,X	SET END
01C8	FF	A0	04		STX	PFILEN	
01CB	DF	08			STX	DIMPNT	
01CD	CE	00	68		LDX	#BUFFER	POINT TO BUFFER
01D0	BD	02	EA		JSR	PCRLF	OUT A CR & LF
01D3	86	21			LDA A	#PRMPTC	
01D5	BD	04	4C		JSR	OUTCH	OUTPUT PROMPT
01D8	BD	02	D0	FILBU2	JSR	INCHAR	GET A CHARACTER
01DB	27	D3			BEQ	FILBUF	
01DD	A7	00			STA A	0,X	SAVE CHAR.
01DF	81	0D			CMP A	#\$0D	IS IT A C.R. ?
01E1	27	08			BEQ	FILBU6	
01E3	08				INX		BUMP THE POINTER
01E4	8C	00	B0		CPX	#BUFFER+72	
01E7	26	EF			BNE	FILBU2	END OF BUFFER?
01E9	20	C5			BRA	FILBUF	
01EB	CE	00	68	FILBU6	LDX	#BUFFER	RESET POINTER
01EE	BD	03	31		JSR	BCDCO1	LINE NO. CONV.
01F1	DF	31			STX	XTEMP2	SAVE POINTER
01F3	BD	03	7B		JSR	FNDKEY	CHECK KEY WORD
01F6	4D				TST A		
01F7	26	1A			BNE	FILBU8	IF NONZERO THEN OK
01F9	DE	04			LDX	BUFPNT	POINT TO BUFFER
01FB	A6	00			LDA A	0,X	GET CHARACTER
01FD	81	0D			CMP A	#\$D	IS IT A C.R.?
01FF	26	08			BNE	FILBU7	
0201	D6	28			LDA B	NOEXFL	DIR. EXECUTION?
0203	27	AB			BEQ	FILBUF	
0205	97	12			STA A	CRFLAG	SET FLAG
0207	20	0A			BRA	FILBU8	IT IS OK
0209	BD	07	45	FILBU7	JSR	TSTLET	LET?
020C	27	05			BEQ	FILBU8	
020E	86	10		FILB75	LDA A	#\$10	
0210	7E	04	61		JMP	MISTAK	REPORT ERROR #0
0213	96	3E		FILBU8	LDA A	CHRCNT	GET CHAR. COUNT
0215	90	26			SUB A	NUMCNT	SUB LINE # DIGITS
0217	97	3E			STA A	CHRCNT	SAVE
0219	D6	28			LDA B	NOEXFL	DIRECT EXECUTE ?
021B	26	06			BNE	STUFLN	IF NOT GO PUT LINE
021D	BD	02	EA		JSR	PCRLF	OUTPUT C.R. L.F.
0220	7E	07	41		JMP	RUNEX4	GO TO ROUTINE

## \* PUT LINE IN PROGRAM STORAGE

0223	FE	01	0F	STUFLN	LDX	MEMEND	
------	----	----	----	--------	-----	--------	--

0226	DF	37	STX	CPX1	
0228	DE	31	LDX	XTEMP2	SET POINTER
022A	DF	04	STX	BUFPNT	SAVE POINTER
022C	BD	02 A5	JSR	FNDLIN	GO FIND LINE IN STORE
022F	DF	22	STX	XSAVE	SAVE POINTER
0231	5D		TST B		DID WE FIND IT?
0232	26	20	BNE	INSERT	IF NOT GO INSERT

## \* REPLACE EXISTING LINE WITH NEW ONE

0234	5C		REPLAC	INC B	INC THE COUNTER
0235	A6	00		LDA A 0,X	GET A CHARACTER
0237	08			INX	BUMP THE POINTER
0238	81	0D		CMP A #\$D	IS IT A C.R.?
023A	26	F8		BNE REPLAC	
023C	F7	02 4C	REPLA4	STA B OFFSET2+1	SETUP OFFSET
023F	86	FF		LDA A #\$FF	GET COUNT
0241	50			NEG B	2'S COMP. IT
0242	8D	46		BSR ADJEND	GO FIX END PNTR
0244	DE	22		LDX XSAVE	RESTORE THE POINTER
0246	BC	0D 4D	REPLA5	CPX ENDSTR	END OF STORAGE?
0249	27	07		BEQ REPLA6	
024B	A6	00	OFFSET2	LDA A 0,X	
024D	A7	00		STA A 0,X	MOVE A CHARACTER
024F	08			INX	BUMP THE POINTER
0250	20	F4		BRA REPLA5	REPEAT
0252	DE	22	REPLA6	LDX XSAVE	RESTORE THE POINTER

## \* INSERT A LINE INTO PROGRAM STORAGE

0254	96	12	INSERT	LDA A CRFLAG	LONE C.R. ?
0256	26	2F		BNE INSERT6	
0258	FE	0D 4D		LDX ENDSTR	
025B	D6	3E		LDA B CHRCNT	GET CHAR. COUNT
025D	CB	02		ADD B #2	BIAS FOR LINE NUM.
025F	F7	02 6C		STA B OFFSET+1	SETUP OFFSET
0262	8D	26		BSR ADJEND	FIX END PNTR
0264	9C	22	INSERT2	CPX XSAVE	DONE?
0266	27	07		BEQ INSERT3	
0268	09			DEX	DEC THE POINTER
0269	A6	00		LDA A 0,X	GET A CHAR,
026B	A7	00	OFFSET	STA A 0,X	
026D	20	F5		BRA INSERT2	MOVE IT
026F	09		INSERT3	DEX	
0270	BD	06 68		JSR PUTLB2	PUT LAB
0273	08			INX	BUMP THE POINTER
0274	08			INX	
0275	DF	22	INSERT4	STX XSAVE	SAVE POINTER
0277	DE	04		LDX BUFPNT	
0279	A6	00		LDA A 0,X	GET CHAR*
027B	08			INX	BUMP THE POINTER
027C	DF	04		STX BUFPNT	SAVE
027E	DE	22		LDX XSAVE	RESTOR PNTR
0280	08			INX	
0281	A7	00		STA A 0,X	SAVE IT
0283	81	0D		CMP A #\$D	IS IT A C.R.?
0285	26	EE		BNE INSERT4	
0287	7E	01 B0	INSERT6	JMP FILBUF	60 TO MAIN LOOP

## \* ADJUST THE END OF PROGRAM POINTER

028A	FB	0D 4E	ADJEND	ADD B ENDSTR+1	
028D	B9	0D 4D		ADC A ENDSTR	ADD IN VALUE
0290	D7	3A		STA B CPX2+1	
0292	97	39		STA A CPX2	SET END POINTER
0294	BD	0C B3		JSR CMPX1	
0297	24	07		BCC ADJEN2	

```

0299 F7 0D 4E          STA B   ENDSTR+1
029C B7 0D 4D          STA A   ENDSTR   SAVE NEW POINTER
029F 39                RTS           RETURN
02A0 86 90          ADJEN2 LDA A   #$90   SET ERROR
02A2 7E 04 61          JMP      MISTAK

```

\* TRY TO FIND LINE

```

02A5 96 64          FNDLIN LDA A   NUMBER+2
02A7 D6 63          LDA B   NUMBER+1
02A9 CE 0D 4F  FINDLN LDX      #STORSP   SETUP POINTER
02AC BC 0D 4D  FINDL1 CPX      ENDSTR   END OF STORAGE?
02AF 26 02          BNE      FINDL4
02B1 5C          FINDL2 INC B
02B2 39          RTS           RETURN
02B3 E1 00          FINDL4 CMP B   0,X    CHECK M.S. DIGITS
02B5 22 0A          BHI      FINDL6
02B7 26 F8          BNE      FINDL2
02B9 A1 01          CMP A   1,X    CHECK L.S, DIGITS
02BB 22 04          BHI      FINDL6
02BD 26 F2          BNE      FINDL2
02BF 5F          CLR B
02C0 39          RTS           RETURN
02C1 8D 03          FINDL6 BSR      FNDCRT   GO FIND C.R,
02C3 08          INX           BUMP THE POINTER
02C4 20 E6          BRA      FINDL1   REPEAT

```

\* FIND A C,R, IN STORAGE

```

02C6 36          FNDCRT PSH A
02C7 86 0D          LDA A   #$D      SAVE A
02C9 08          FNDVAL INX           BUMP THE POINTER
02CA A1 00          CMP A   0,X    TEST FOR C.R.
02CC 26 FB          BNE      FNDVAL
02CE 32          PUL A
02CF 39          RTS           RETURN

```

\* INPUT

```

02D0 BD 01 09  INCHAR JSR      INCH    GET THE CHAR.
02D3 81 08          CMP A   #BACKSP  IS IT A BACKSPACE?
02D5 26 0B          BNE      INCHR2
02D7 8C 00 68          CPX      #BUFFER BEGINNING OF BUF ?
02DA 27 0D          BEQ      INCHR4
02DC 09          DEX           BACKUP ONE POS.
02DD 7A 00 3E          DEC      CHRCNT  DEC CHAR. COUNT
02E0 20 EE          BRA      INCHAR
02E2 81 18          INCHR2 CMP A   #DELCOD DELETE LINE ?
02E4 27 03          BEQ      INCHR4
02E6 7C 00 3E          INC      CHRCNT
02E9 39          INCHR4 RTS           RETURN

```

\* PRINT CARRIAGE RETURN & LINEFEED

```

02EA DF 22          PCRLF STX      XSAVE   SAVE X REG
02EC CE 03 01          LDX      #CRLFST  POINT TO STRING
02EF A6 00          PDATA1 LDA A   0,X    GET CHAR
02F1 81 04          CMP A   #4      IS IT 4?
02F3 27 06          BEQ      PCRLF2
02F5 BD 04 4C          JSR      OUTCH   OUTPUT CHAR
02F8 08          INX           BUMP THE POINTER
02F9 20 F4          BRA      PDATA1   REPEAT
02FB DE 22          PCRLF2 LDX      XSAVE   RESTORE X REG
02FD 7F 00 1D          CLR      FLDCNT  ZERO FIELD COUNT
0300 39          RTS           RETURN

```

```

0301 0D          CRLFST FCB      $D,$A,0,0,0,0,4
0302 0A 00

```

0304 00 00  
0306 00 04

\* TEST FOR STATEMENT TERMINATOR

0308 81 0D     TSTTRM    CMP   A    #\$D            C,R,?  
030A 27 02                BEQ        TSTTR2  
030C 81 3A                CMP   A    #' :           COLON?  
030E 39                TSTTR2    RTS                RETURN

\* CLEAR NUMBER THROUGH NUMBER+2

030F BD 0B 51    UPSCLR    JSR        STAKUP  
0312 4F           CLRNUM    CLR   A  
0313 97 62                STA   A    NUMBER  
0315 97 63                STA   A    NUMBER+1  
0317 97 64                STA   A    NUMBER+2  
0319 39                RTS

\* CONVERT NUMBER TO PACKED BCD

031A 8D F6           BCDCON    BSR        CLRNUM        CLEAR NUMBER  
031C 97 28                STA   A    NOEXFL  
031E 97 27                STA   A    NEGFLG  
0320 97 26                STA   A    NUMCNT  
0322 BD 03 68           JSR        SKIPSP        SKIP SPACES  
0325 81 2B                CMP   A    #' +        IS IT A +?  
0327 27 07                BEQ        BCDC01  
0329 81 2D                CMP   A    #' -        IS IT A - ?  
032B 26 04                BNE        BCDC01  
032D 73 00 27           COM        NEGFLG        SET FLAG  
0330 08                BCDC01    INX  
0331 BD 0C E3           BCDC01    JSR        CLASS        GET A DIGIT  
0334 C1 03                CMP   B    #3           IS IT A NUMBER?  
0336 27 05                BEQ        BCDC02  
0338 96 27                LDA   A    NEGFLG  
033A 7E 0B EA           JMP        FIXSIN        GO FIX UP THE SIGN  
033D 08                BCDC02    INX           BUMP THE POINTER  
033E 97 28                STA   A    NOEXFL       SET NO EXEC FLU  
0340 84 0F                AND   A    #\$0F        MASK OFF ASCII  
0342 C6 04                LDA   B    #4           SET COUNTER  
0344 78 00 64           BCDC04    ASL        NUMBER+2  
0347 79 00 63                ROL        NUMBER+1  
034A 79 00 62                ROL        NUMBER       SHIFT PREV. OVER  
034D 5A                DEC   B                DEC THE COUNTER  
034E 26 F4                BNE        BCDC04  
0350 9B 64                ADD   A    NUMBER+2  
0352 97 64                STA   A    NUMBER+2       SAVE NEW VALUE  
0354 7C 00 26                INC        NUMCNT       INC NUMBER CNTR  
0357 20 D8                BRA        BCDC01

\* FIND NEXT BLOCK

0359 DE 04           NXTBLK    LDX        BUFPNT        RESTORE POINTER  
035B A6 00           NXTBL4    LDA   A    0,X        GET A CHAR.  
035D 81 20                CMP   A    #'           IS IT A SPACE?  
035F 27 07                BEQ        SKIPSP  
0361 08                INX                BUMP THE POINTER  
0362 20 F7                BRA        NXTBL4       REPEAT

\* CONVERT AND SKIP

0364 8D B4           CONSKP    BSR        BCDCON  
0366 09                DEX

\* SKIP ALL SPACES

0367 08                SKPSP0    INX



```

0368 A6 00      SKIPSP  LDA A  0,X      GET CHR FROM BUF
036A 81 20      CMP A  #$20      IS IT A SPACE?
036C 27 F9      BEQ      SKPSP0
036E 39          SKIPS4  RTS          RETURN

```

\* FIND NEXT BLOCK NOT EXPECTING A SPACE

```

036F DE 04      NXTSPC  LDX      BUFNT   SET POINTER
0371 BD 0C E3    NXTSP4  JSR      CLASS   GO CLASSIFY
0374 C1 02      CMP B  #2        IS IT A LETTER?
0376 26 F0      BNE      SKIPSP
0378 08          INX          BUMP THE POINTER
0379 20 F6      BRA      NXTSP4

```

\* FIND KEY WORD IF POSSIBLE

```

037B BD 03 68    FNDKEY  JSR      SKIPSP  SKIP SPACES
037E DF 04      STX      BUFNT   SAVE THE POINTER
0380 DF 22      STX      XSAVE
0382 CE 01 11    LDX      #KEYTBL  POINT TO KEY WORDS
0385 C6 05      FNDKE2  LDA B  #5
0387 A1 00      FNDKE4  CMP A  0,X      TEST THE CHARACTER
0389 26 12      BNE      FNDKE6
038B DF 0A      STX      XTEMP3  SAVE POINTER
038D DE 22      LDX      XSAVE
038F 08          INX          BUMP POINTER
0390 A6 00      LDA A  0,X      GET CHAR.
0392 DF 22      STX      XSAVE
0394 DE 0A      LDX      XTEMP3  REST. PNTR.
0396 08          INX
0397 5A          DEC B
0398 C1 02      CMP B  #2
039A 26 EB      BNE      FNDKE4  IF NOT DONE REPEAT
039C 39          FNDKE5  RTS      RETURN
039D 08          FNDKE6  INX      BUMP THE COUNTER
039E 5A          DEC B
039F 26 FC      BNE      FNDKE6
03A1 A6 00      LDA A  0,X      GET CHARACTER
03A3 27 F7      BEQ      FNDKE5  IF ZERO, END OF LIST
03A5 DF 0A      STX      XTEMP3  SAVE POINTER
03A7 DE 04      LDX      BUFNT
03A9 DF 22      STX      XSAVE
03AB A6 00      LDA A  0,X      GET NEW CHAR.
03AD DE 0A      LDX      XTEMP3  RESTORE POINTER
03AF 20 D4      BRA      FNDKE2  REPEAT

```

\* OUTPUT A NUMBER FROM PACKED BCD BYTES

```

03B1 CE 00 62    OUTBCD  LDX      #NUMBER  SET POINTER
03B4 C6 02      OUTBCI  LDA B  #2        SET COUNTER
03B6 0C          CLC
03B7 A6 00      LDA A  0,X      GET A WORD
03B9 2A 19      BPL      OUTBC4  IF NOT NEG JMP AHEAD
03BB 86 2D      LDA A  #'-'
03BD BD 04 4C    JSR      OUTCH      OUTPUT A
03C0 7C 00 1D    INC      FLDCNT
03C3 20 0F      BRA      OUTBC4
03C5 A6 00      OUTBC2  LDA A  0,X      GET DIGITS
03C7 85 F0      BIT A  #$F0      MASK
03C9 25 02      BCS      OUTBC3
03CB 27 07      BEQ      OUTBC4  JMP IF ZEROES
03CD BD 04 44    OUTBC3  JSR      OUTHL  OUTPUT A DIGIT
03D0 7C 00 1D    INC      FLDCNT
03D3 0D          SEC
03D4 A6 00      OUTBC4  LDA A  0,X      GET A DIGIT
03D6 C5 FF      BIT B  #$FF      LAST DIGIT?
03D8 27 06      BEQ      OUTBC6

```

```

03DA 85 0F          BIT A  #$0F      MASK
03DC 25 02          BCS  OUTBC6
03DE 27 07          BEQ  OUTBC8      JMP IF ZEROES
03E0 BD 04 48  OUTBC6 JSR  OUTHR      OUTPUT A DIGIT
03E3 7C 00 1D          INC  FLDCNT
03E6 0D          SEC
03E7 08          OUTBC8 INX          BUMP THE POINTER
03E8 5A          DEC B      DEC THE COUNTER
03E9 2A DA          BPL  OUTBC2      REPEAT IF NOT DONE
03EB 39          RTS          RETURN

```

## \* LIST USERS PROGRAM

```

03EC BD 03 6F  LIST  JSR  NXTSPC      FIND NEXT
03EF 81 0D          CMP A  #$D
03F1 27 25          BEQ  LIST3
03F3 BD 03 1A          JSR  BCDCON      GET LINE NUM
03F6 DF 04          STX  BUFPTNT      SAVE POINTER
03F8 BD 02 A5          JSR  FNDLIN      FIND LINE
03FB DF 22          STX  XSAVE        SAVE IT
03FD BD 03 6F          JSR  NXTSPC
0400 81 0D          CMP A  #$D      C.R.?
0402 26 05          BNE  LIST1
0404 7C 00 1B          INC  SUBCNT      SET TO 1
0407 20 0B          BRA  LIST2
0409 08          LIST1 INX          BUMP THE POINTER
040A BD 03 68          JSR  SKIPSP
040D BD 03 1A          JSR  BCDCON      GET COUNT
0410 96 64          LDA A  NUMBER+2
0412 97 1B          STA A  SUBCNT      SAVE IT
0414 DE 22          LIST2 LDX        POINT TO LINE
0416 20 03          BRA  LIST4
0418 CE 0D 4F  LIST3 LDX  #STORSP      SET POINTER
041B BC 0D 4D  LIST4 CPX  ENDSTR      END OF STORAGE?
041E 27 21          BEQ  LIST8
0420 BD 02 EA          JSR  PCRLF      OUTPUT A
0423 C6 01          LDA B  #1        SETUP COUNTER
0425 0C          CLC
0426 8D 9D          BSR  OUTBC2      OUT LINE NUMBER
0428 A6 00          LIST5 LDA A  0,X    GET A CHARACTER
042A 81 0D          CMP A  #$D      IS IT A C.R.?
042C 27 05          BEQ  LIST6
042E 8D 1C          BSR  OUTCH      OUTPUT CHARACTER
0430 08          INX          BUMP THE POINTER
0431 20 F5          BRA  LIST5      REPEAT
0433 08          LIST6 INX          BUMP THE POINTER
0434 96 1B          LDA A  SUBCNT      GET COUNT
0436 27 E3          BEQ  LIST4
0438 8B 99          ADD A  #$99      DEC THE COUNT
043A 19          DAA
043B 27 04          BEQ  LIST8
043D 97 1B          STA A  SUBCNT      SAVE
043F 20 DA          BRA  LIST4
0441 7E 01 B0  LIST8 JMP  FILBUF
0444 44          OUTHL  LSR A
0445 44          LSR A
0446 44          LSR A
0447 44          LSR A      MOVE TO BOTTOM
0448 84 0F          OUTHR AND A  #$0F    MASK
044A 8B 30          ADD A  #$30    BIAS
044C BD 01 0C  OUTCH JSR  BREAK      CHECK FOR BREAK
044F 7E 01 06          JMP  OUTEEE    GO PRINT

```

## \* INTERNAL BREAK ROUTINE

```

0452 36          INTBRK PSH A
0453 B6 80 04          LDA A  PIAADR    CHECK

```

```

0456 2A 02          BPL      BREAK2
0458 32            PUL A      GET CHAR
0459 39            RTS        RETURN
045A B6 80 04      BREAK2 LDA A  PIAADR
045D 2A FB          BPL      BREAK2
045F 86 99          LDA A  #$99      SET ERROR

      * OUTPUT ERROR MESSAGE

0461 36            MISTAK PSH A      SAVE A
0462 BD 02 EA      JSR      PCRLF    OUTPUT A CR & LF
0465 CE 04 98      MISTA1 LDX      #ERRSTR POINT TO ERROR STRING
0468 BD 02 EF      JSR      PDATA1   OUTPUT IT
046B 32            PUL A      RESTORE A
046C 36            PSH A      SAVE A
046D BD 04 44      JSR      OUTHL    OUTPUT DIGIT
0470 32            MISTA2 PUL A      RESTORE A
0471 BD 04 48      JSR      OUTHR    OUT 1'S DIGIT
0474 D6 19          LDA B      RUNFLG RUNNING?
0476 26 03          BNE      RUNER1
0478 7E 01 B0      MISTA4 JMP      FILBUF
047B CE 04 A1      RUNER1 LDX      #ERSTR2 POINT TO STRING
047E BD 02 EF      JSR      PDATA1   OUTPUT IT
0481 DE 04          LDX      BUFNT    SET POINTER
0483 09            RUNER2 DEX        DEC THE POINTER
0484 8C 0D 4F      CPX      #STORSP BEGINNING?
0487 27 07          BEQ      RUNER4
0489 A6 00          LDA A  0,X      GET CHAR
048B 81 0D          CMP A  #$D      C.R.?
048D 26 F4          BNE      RUNER2
048F 08            INX          BUMP THE POINTER
0490 C6 01          RUNER4 LDA B  #1
0492 0C            CLC
0493 BD 03 C5      JSR      OUTBC2    OUT LINE NUM.
0496 20 E0          BRA      MISTA4
0498 07            ERRSTR FCB      7
0499 45            FCC      ;ERROR #;
049A 52 52
049C 4F 52
049E 20 23
04A0 04            FCB      4

04A1 20            ERSTR2 FCC      ; AT ;
04A2 41 54
04A4 20
04A5 04            FCB      4

      * PRINT ROUTINE

04A6 BD 03 6F      PRINT JSR      NXTSPC FIND NEXT BLOCK
04A9 BD 03 08      PRINT0 JSR      TSTTRM
04AC 26 03          BNE      FIELD1
04AE 7E 05 3C      JMP      PRINT8
04B1 7F 00 12      FIELD1 CLR      CRFLAG
04B4 81 2C          CMP A  #',      IS IT A ", "
04B6 26 20          BNE      PRINT2
04B8 D6 1D          LDA B  FLDCNT    GET COUNT
04BA 86 20          FIELD2 LDA A  #'    SPACE
04BC BD 04 4C      JSR      OUTCH    OUTPUT A SPACE
04BF 5C            INC B
04C0 C5 07          BIT B  #7        END OF FIELD?
04C2 26 F6          BNE      FIELD2
04C4 C1 47          CMP B  #$47      END OF LINE?
04C6 22 04          BHI      FIELD3
04C8 D7 1D          STA B  FLDCNT    SAVE FIELD INFO
04CA 20 03          BRA      PRINT1
04CC BD 02 EA      FIELD3 JSR      PCRLF OUT A C.R. & L.F.
04CF 7C 00 12      PRINT1 INC      CRFLAG SET FLAG

```

```

04D2 08          INX          BUMP THE POINTER
04D3 BD 03 68    JSR          SKIPSP
04D6 20 D1      BRA          PRINT0
04D8 81 3B      PRINT2  CMP A   #' ;      IS IT A " ; "
04DA 27 F3      BEQ          PRINT1
04DC 81 22      CMP A   #' "      IS IT A QUOTE?
04DE 26 05      BNE          PRINT4
04E0 08          INX          BUMP THE POINTER
04E1 8D 64      BSR          PSTRNG  OUTPUT STRING
04E3 20 49      BRA          PRINT6
04E5 7F 00 17   PRINT4  CLR          TABFLG  CLEAR FLAG
04E8 81 54      CMP A   #' T      IS IT A T?
04EA 26 06      BNE          PRIN45
04EC 97 17      STA A   TABFLG  SET FLAG
04EE 86 41      LDA A   #' A
04F0 20 06      BRA          PRIN47
04F2 81 53      PRIN45  CMP A   #' S      IS IT A S?
04F4 26 2E      BNE          PRIN55
04F6 86 50      LDA A   #' P
04F8 A1 01      PRIN47  CMP A   1,X
04FA 26 28      BNE          PRIN55
04FC BD 03 71    JSR          NXTSP4  FIND NEXT
04FF BD 0A 26    JSR          EXPR    EVALUATE
0502 BD 06 1E    JSR          BINCON  CONVERT
0505 D6 64      LDA B   NUMBER+2
0507 27 25      BEQ          PRINT6
0509 96 17      LDA A   TABFLG  CHECK FLAG
050B 27 07      BEQ          PRINT5
050D 5A          DEC B
050E D1 1D      CMP B   FLDCNT  CHECK COUNT
0510 23 1C      BLS          PRINT6
0512 20 02      BRA          PRIN51
0514 DB 1D      PRINT5  ADD B   FLDCNT
0516 86 20      PRIN51  LDA A   #'      SPACE
0518 BD 04 4C    JSR          OUTCH  OUTPUT SPACE
051B 7C 00 1D    INC          FLDCNT  BUMP COUNTER
051E D1 1D      CMP B   FLDCNT
0520 26 F4      BNE          PRIN51  REPEAT
0522 20 0A      PRIN52  BRA          PRINT6
0524 BD 0A 26   PRIN55  JSR          EXPR  EVAL EXPRESSION
0527 DF 22      STX          XSAVE  SAVE POINTER
0529 BD 03 B1    JSR          OUTBCD  OUTPUT VALUE
052C DE 22      LDX          XSAVE  RESTORE
052E BD 0C DE   PRINT6  JSR          SKYCLS
0531 5A          DEC B
0532 26 03      BNE          PRINT7  CHECK FOR ERROR
0534 7E 04 A9    JMP          PRINT0
0537 86 31      PRINT7  LDA A   #$31
0539 7E 04 61    JMP          MISTAK
053C 7D 00 12   PRINT8  TST          CRFLAG  C.R. ?
053F 26 03      BNE          PRINT9
0541 BD 02 EA    JSR          PCRLF  OUTPUT C.R. L.F
0544 7E 07 04   PRINT9  JMP          RUNEXC

```

\* PRINT STRING ROUTINE

```

0547 A6 00      PSTRNG  LDA A   0,X      GET A CHAR.
0549 81 22      CMP A   #' "      IS I T A QUOTE?
054B 27 0E      BEQ          PSTRN4
054D BD 03 08    JSR          TSTTRM  IS IT A C.R.?
0550 27 0D      BEQ          PSTRN8
0552 BD 04 4C    JSR          OUTCH  OUTPUT CHARACTER
0555 7C 00 1D    INC          FLDCNT  BUMP FIELD CNT
0558 08          INX          BUMP THE POINTER
0559 20 EC      BRA          PSTRNG  REPEAT
055B 08          PSTRN4  INX
055C 7E 03 68    JMP          SKIPSP
055F 86 32      PSTRN8  LDA A   #$32

```

```

0561 7E 04 61          JMP      MISTAK      REPORT ERROR

      * FIND LABEL ROUTINE

0564 DF 04          FNDVAR  STX      BUFNT      SAVE POINTER
0566 BD 0C E5          JSR      CLASS1      GO CLASSIFY CHAR.
0569 C1 02          CMP      B      #2      CHECK FOR LETTER
056B 26 2F          BNE      FNDL25      ERROR
056D 7F 00 20          CLR      XTEMP
0570 16          TAB
0571 48          ASL      A          SAVE LABEL
0572 1B          ABA          MULT IT BY 2
0573 80 13          SUB      A      #$13      ADD IT
0575 97 21          STA      A      XTEMP+1
0577 DE 20          LDX      XTEMP      POINT TO IT
0579 39          RTS          RETURN

      * FIND DIMENSIONED VARIABLE

057A A6 00          FNDLB0  LDA      A      0,X
057C 08          FNDLBL  INX
057D 7F 00 18          CLR      DIMFLG      ADVANCE POINTER
0580 8D E2          BSR      FNDVAR      GO FIND VAR.
0582 5F          CLR      B
0583 A6 00          LDA      A      0,X      GET CHAR.
0585 81 0A          CMP      A      #$0A      CHECK FOR 1 DIM
0587 27 06          BEQ      FNDLB2
0589 81 0B          CMP      A      #$0B      CHECK IF 2 DIM
058B 27 01          BEQ      FNDLB1
058D 39          RTS
058E 5C          FNDLB1  INC      B          SET FLAG-2 DIM
058F A6 01          FNDLB2  LDA      A      1,X      SET POINTER
0591 36          PSH      A
0592 A6 02          LDA      A      2,X
0594 36          PSH      A
0595 37          PSH      B          SAVE B
0596 BD 03 6F          JSR      NXTSPC      FIND NEXT
0599 33          PUL      B
059A 81 28          CMP      A      #' (      IS IT A PAREN?
059C 26 71          FNDL25  BNE      FNDLB9
059E 5D          TST      B
059F 27 13          BEQ      FNDLB3
05A1 08          INX
05A2 BD 0A 29          JSR      EXPRO      GO EVALUATE
05A5 96 64          LDA      A      NUMBER+2      GET RESULT
05A7 36          PSH      A          SAVE IT
05A8 BD 0B 62          JSR      STAKDN      RESTORE
05AB BD 03 6F          JSR      NXTSPC      FIND NEXT
05AE 81 2C          CMP      A      #',      IS IT A COMMA?
05B0 26 5D          BNE      FNDLB9
05B2 20 02          BRA      FNDLB4
05B4 4F          FNDLB3  CLR      A
05B5 36          PSH      A          SET ROWV
05B6 4C          FNDLB4  INC      A
05B7 97 18          STA      A      DIMFLG      SET FLAG
05B9 08          INX
05BA BD 0A 29          JSR      EXPRO
05BD 08          INX
05BE DF 04          STX      BUFNT      SAVE POINTER
05C0 32          PUL      A
05C1 97 14          STA      A      ROWVAR      SAVE
05C3 32          PUL      A
05C4 97 21          STA      A      XTEMP+1      SAVE
05C6 32          PUL      A
05C7 97 20          STA      A      XTEMP      SAVE
05C9 DE 20          LDX      XTEMP      SET POINTER
05CB A6 00          LDA      A      0,X      GET CHAR
05CD 97 16          STA      A      COLCON      SAVE IT

```

```

05CF 08          INX          BUMP THE POINTER
05D0 08          INX
05D1 DF 20       STX      XTEMP
05D3 BD 03 0F    JSR      UPSCLR
05D6 96 14       LDA A  ROWVAR  GET VAR.
05D8 DE 20       LDX      XTEMP
05DA 09          DEX          DEC POINTER
05DB A1 00       CMP A  0,X    CHECK
05DD 22 30       BHI      FNDLB9
05DF 97 64       STA A  NUMBER+2
05E1 BD 03 0F    JSR      UPSCLR  PUSH STACK
05E4 96 16       LDA A  COLCON  GET CONST,
05E6 91 5E       CMP A  AC-1    CHECK
05E8 27 02       BEQ      FNDL45
05EA 23 23       BLS      FNDLB9  ERROR!
05EC 8B 01       FNDL45 ADD A  #1
05EE 19          DAA          BIAS IT
05EF 97 64       STA A  NUMBER+2
05F1 BD 0B F4    JSR      MULT   GO MULTIPLY
05F4 BD 0B CA    JSR      ADD    GO ADD
05F7 BD 06 14    FNDLB5 JSR      TIMTHR

```

\* ROUTINE TO ADD VALUE TO X-REG.

```

05FA 96 20       ADDX   LDA A  XTEMP  GET M.S.BYTE
05FC D6 21       LDA B  XTEMP+1
05FE DB 64       ADD B  NUMBER+2
0600 99 63       ADC A  NUMBER+1
0602 97 20       STA A  XTEMP  SAVE SUM
0604 D7 21       STA B  XTEMP+1
0606 BD 0B 62    JSR      STAKDN
0609 DE 20       LDX      XTEMP  SET POINTER
060B 7F 00 18    CLR      DIMFLG  RESTORE FLAG
060E 39          RTS          RETURN

060F 86 14       FNDLB9 LDA A  #$14  SET ERROR
0611 7E 04 61    JMP      MISTAK  GO REPORT

```

\* ROUTINE TO MULTIPLY BY 3

```

0614 BD 03 0F    TIMTHR JSR      UPSCLR
0617 86 03       LDA A  #$3     SET MULTIPLIER
0619 97 64       STA A  NUMBER+2
061B BD 0B F4    JSR      MULT   GO MULTIPLY

```

\* BCD TO BINARY CONVERT.

```

061E 96 64       BINCON LDA A  NUMBER+2  GET LS BYTE
0620 36          PSH A          SAVE
0621 96 63       LDA A  NUMBER+1
0623 36          PSH A          SAVE:
0624 5F          CLR B
0625 D7 63       STA B  NUMBER+1
0627 D7 64       STA B  NUMBER+2  INITIALIZE
0629 96 62       LDA A  NUMBER
062B 8D 12       BSR      ADSHF1  ADD AND SHIFT
062D 32          PUL A
062E 36          PSH A
062F 8D 0A       BSR      ADSHF0  GO ADD IN AND SHIFT
0631 32          PUL A          GET MS BYTE AGAIN
0632 8D 0B       BSR      ADSHF1  GO ADD IN AND SHIFT
0634 32          PUL A          GET LS BYTE
0635 36          PSH A
0636 8D 03       BSR      ADSHF0
0638 32          PUL A
0639 20 1D       BRA      ADDIN   GO ADD IN ONES
063B 44          ADSHF0 LSR A
063C 44          LSR A

```

```

063D 44          LSR A
063E 44          LSR A      MOVE TO LS HALF
063F 8D 17      ADSHF1 BSR      ADDIN      GO ADD IN
0641 D6 63          LDA B      NUMBER+1
0643 48          ASL A
0644 59          ROL B      MULT BY 2
0645 37          PSH B
0646 36          PSH A      SAVE
0647 48          ASL A
0648 59          ROL B
0649 48          ASL A
064A 59          ROL B      MULT BY 4, =*8
064B 97 64          STA A      NUMBER+2
064D 32          PUL A
064E D7 63          STA B      NUMBER+1
0650 8D 08          BSR      ADDIN1      GO ADD IN
0652 32          PUL A
0653 9B 63          ADD A      NUMBER+1
0655 97 63          STA A      NUMBER+1      MULTIPLY BY TEN
0657 39          RTS
0658 84 0F          ADDIN AND A      #$0F      MASK
065A 9B 64          ADDIN1 ADD A      NUMBER+2
065C 97 64          STA A      NUMBER+2
065E 24 03          BCC      ADDIN2      CHECK FOR CARRY
0660 7C 00 63      INC      NUMBER+1
0663 39          ADDIN2 RTS

```

\* PUT LABLE ROUTINE

```

0664 96 62      PUTLBL LDA A      NUMBER
0666 A7 00          STA A      0,X      PUT M.S. BYTE
0668 96 62      PUTLB2 LDA A      NUMBER      +1
066A A7 01          STA A      1,X      PUT NEXT
066C 96 64          LDA A      NUMBER+2
066E A7 02          STA A      2,X      PUT L.S. BYTE
0670 39          RTS      RETURN

```

\* DIMENSION

```

0671 DE 06      DIM      LDX      FORSTK      SET BOUNDS
0673 DF 37          STX      CPX1
0675 BD 03 6F      DIMN JSR      NXTSPC
0678 BD 03 68      JSR      SKIPSP      CLASSIFY
067B BD 05 64      JSR      FNDVAR
067E DF 0A          STX      XTEMP3      SAVE IT
0680 BD 03 6F      JSR      NXTSPC      GET TO NEXT
0683 81 28          CMP A      #' (      IS IT A PARENT
0685 26 20          BNE      DIM9
0687 08          DIM01 INX
0688 BD 03 64      JSR      CONSKP      BUMP THE POINTER
068B 81 29          CMP A      #')      CONVERT DIM
068D 26 05          BNE      DIM1      IS IT A PAREN
068F 4F          CLR A
0690 5F          CLR B
0691 36          PSH A      SAVE IT
0692 20 18          BRA      DIM2
0694 81 2C          DIM1 CMP A      #',      COMMA?
0696 26 0F          BNE      DIM9      ERROR!
0698 96 64          LDA A      NUMBER+2
069A 27 0B          BEQ      DIM9
069C 36          PSH A      SAVE
069D 08          INX      BUMP THE POINTER
069E BD 03 64      JSR      CONSKP      CONVERT
06A1 C6 01          LDA B      #1
06A3 81 29          CMP A      #')      PAREN?
06A5 27 05          BEQ      DIM2
06A7 86 40          DIM9 LDA A      #$40      SET ERROR
06A9 7E 04 61      JMP      MISTAK      REPORT

```

06AC	96	64	DIM2	LDA A	NUMBER+2	
06AE	27	F7		BEQ	DIM9	
06B0	36			PSH A		SAVE
06B1	DF	04		STX	BUFPNT	SAVE POINTER
06B3	DE	0A		LDX	XTEMP3	SET X
06B5	86	0A		LDA A	#\$0A	
06B7	1B			ABA		SET MARKER
06B8	A7	00		STA A	0,X	SAVE IT
06BA	96	08		LDA A	DIMPNT	GET POINTER
06BC	A7	01		STA A	1,X	SAVE IT
06BE	96	09		LDA A	DIMPNT+1	
06C0	A7	02		STA A	2,X	
06C2	DE	08		LDX	DIMPNT	SET POINTER
06C4	32			PUL A		
06C5	A7	00		STA A	0,X	SAVE 1ST DIM
06C7	08			INX		BUMP THE POINTER
06C8	33			PUL B		
06C9	E7	00		STA B	0,X	SAVE 2ND DIM
06CB	08			INX		
06CC	DF	20		STX	XTEMP	SAVE POINTER
06CE	8B	01		ADD A	#1	
06D0	19			DAA		BIAS
06D1	36			PSH A		
06D2	17			TBA		
06D3	8B	01		ADD A	#1	BIAS
06D5	19			DAA		ADJUST
06D6	16			TAB		SAVE
06D7	BD	03 12		JSR	CLRNUM	CLEAR STORAGE
06DA	D7	64		STA B	NUMBER+2	
06DC	BD	03 0F		JSR	UPSCLR	GO CLEAR
06DF	32			PUL A		
06E0	97	64		STA A	NUMBER+2	
06E2	BD	0B F4		JSR	MULT	MULTIPLY
06E5	BD	05 F7		JSR	FNDLB5	GO FIX X
06E8	BD	0C B1		JSR	CMPX	TEST BOUNDS
06EB	23	03		BLS	DIM5	
06ED	7E	02 A0		JMP	ADJEN2	
06F0	DF	08	DIM5	STX	DIMPNT	SAVE RESULT
06F2	DE	04		LDX	BUFPNT	RESTORE F'NTR
06F4	08			INX		
06F5	BD	03 68		JSR	SKIPSP	SKIP SPACES
06F8	BD	03 08		JSR	TSTTRM	
06FB	27	07		BEQ	RUNEXC	
06FD	08			INX		BUMP THE POINTER
06FE	7E	06 78		JMP	DIMN	

\* EXTERNAL ROUTINE JUMP

0701	BD	1F 00	EXTRNL	JSR	EXTERN	GO TO IT
------	----	-------	--------	-----	--------	----------

\* RUN EXECUTIVE

0704	4F		RUNEXC	CLR A		
0705	97	12		STA A	CRFLAG	
0707	97	1C		STA A	LETFLG	
0709	97	18		STA A	DIMFLG	
070B	97	2C		STA A	STKCNT	
070D	96	19		LDA A	RUNFLG	RUN MODE?
070F	26	03		BNE	RUNEX0	
0711	7E	01 B0	RUNEXA	JMP	FILBUF	
0714	DE	04	RUNEX0	LDX	BUFPNT	SET POINTER
0716	86	0D	RUNE05	LDA A	#\$D	
0718	C6	3A		LDA B	#':	SETUP TERMINATORS
071A	A1	00	RUNEX1	CMP A	0,X	C.R. ?
071C	27	07		BEQ	RUNEX2	
071E	E1	00		CMP B	0,X	IS IT A ':' ?
0720	27	0A		BEQ	RUNE27	
0722	08			INX		BUMP THE POINTER



```

0723 20 F5          BRA      RUNEX1    REPEAT
0725 08          RUNEX2 INX
0726 BC 0D 4D    RUNE22 CPX      ENDSTR  END OF STORAGE?
0729 27 E6          BEQ      RUNEXA
072B 08          RUNE25 INX          BUMP THE POINTER
072C 08          RUNE27 INX
072D BD 01 0C    JSR      BREAK    GO CHECK BREAK
0730 BD 03 7B    RUNEX3 JSR      FNDKEY  FIND KEY WORD
0733 4D          TST A
0734 26 0B          BNE      RUNEX4
0736 DE 04          LDX      BUFNT    SET POINTER
0738 8D 0B          BSR      TSTLET
073A 27 05          BEQ      RUNEX4
073C 86 10          LDA A   #$10
073E 7E 04 61    RUNE35 JMP      MISTAK
0741 EE 00    RUNEX4 LDX      0,X
0743 6E 00          JMP      0,X      GO TO ROUTINE

```

## \* TEST FOR IMPLIED LET

```

0745 BD 0C E3    TSTLET JSR      CLASS  CHECK CHAR.
0748 C1 02          CMP B   #2        LETTER?
074A 26 12          BNE      TSTLE2
074C 08          INX
074D BD 03 68    JSR      SKIPSP  BUMP THE POINTER
0750 81 3D          CMP A   #'=      SKIP SPACES
0752 27 04          BEQ      TSTLE1  EQUALS?
0754 81 28          CMP A   #'(      LEFT PARENT
0756 26 06          BNE      TSTLE2
0758 CE 01 23    TSTLE1 LDX      #LETADR SET POINTER
075B 97 1C          STA A   LETFLG    SET FLAG
075D 5F          CLR B
075E 39          TSTLE2 RTS

```

## \* RUN ROUTINE

```

075F BD 01 8B    RUN      JSR      CLRBEG
0762 BD 01 95          JSR      CLREND
0765 FE 01 0F          LDX      MEMEND
0768 DF 06          STX      FORSTK
076A CE 0D 4F          LDX      #STORSP  SET POINTER
076D 7C 00 19          INC      RUNFLG
0770 20 B4          BRA      RUNE22

```

## \* LET ROUTINE

```

0772 DE 04          LET      LDX      BUFNT
0774 96 1C          LDA A   LETFLG  TEST FLAG
0776 26 03          BNE      LET2
0778 BD 03 59          JSR      NXTBLK  FIND NEXT
077B BD 09 65    LET2   JSR      EXPEQU
077E 7E 07 04          JMP      RUNEXC

```

## \* GOTO ROUTINE

```

0781 BD 03 6F    GOTO    JSR      NXTSPC  FIND BLOCK
0784 BD 0A 26    GOTO1   JSR      EXPR    GO EVALUATE
0787 BD 02 A5    GOTO2   JSR      FNDLIN  GO FIND LINE
078A 5D          GOTO3   TST B          FIND?
078B 27 05          BEQ      GOTO5
078D 86 16          LDA A   #$16      SET ERROR
078F 7E 04 61    GOTO4   JMP      MISTAK  REPORT
0792 5C          GOTO5   INC B
0793 D7 19          STA B   RUNFLG    SET RUN FLAG
0795 7E 07 26          JMP      RUNE22

```

## \* INPUT ROUTINE

0798	BD	03	6F	INPUT	JSR	NXTSPC	FIND NEXT
079B	7F	00	13	INPUT0	CLR	QMFLAG	CLEAR FLAG
079E	BD	03	68	INPUT1	JSR	SKIPSP	SKIP SPACES
07A1	81	22			CMP A	#'"	IS IT A QUOTE?
07A3	26	06			BNE	INPUT2	
07A5	08				INX		BUMP THE POINTER
07A6	BD	05	47		JSR	PSTRNG	OUTPUT STRING
07A9	20	3B			BRA	INPUT6	
07AB	BD	05	7C	INPUT2	JSR	FNDLBL	FIND LABEL
07AE	DF	33			STX	XTEMP4	SAVE POINTER
07B0	CE	00	68	INPUT3	LDX	#BUFFER	SET POINTER
07B3	96	13			LDA A	QMFLAG	TEST FLAG
07B5	26	07			BNE	INPUT4	
07B7	86	3F			LDA A	#'?	
07B9	97	13			STA A	QMFLAG	SET FLAG
07BB	BD	04	4C		JSR	OUTCH	OUT A ?
07BE	BD	01	09	INPUT4	JSR	INCH	GET A DIGIT
07C1	81	18			CMP A	#DELCOD	DELETE?
07C3	26	05			BNE	INPU45	
07C5	7F	00	13		CLR	QMFLAG	
07C8	20	E6			BRA	INPUT3	
07CA	A7	00		INPU45	STA A	0,X	SAVE IT
07CC	08				INX		
07CD	81	2C			CMP A	#',	IS IT COMMA?
07CF	27	09			BEQ	INPUT5	
07D1	81	0D			CMP A	#\$D	IS IT A C.R.?
07D3	26	E9			BNE	INPUT4	
07D5	97	12			STA A	CRFLAG	SET FLAG
07D7	BD	02	EA		JSR	PCRLF	OUTPUT A CR & LF
07DA	CE	00	68	INPUT5	LDX	#BUFFER	SET POINTER
07DD	BD	03	1A		JSR	BCDCON	GO CNVRT NUM.
07E0	DE	33			LDX	XTEMP4	
07E2	8D	2D			BSR	LABLS2	
07E4	DF	04			STX	BUFPNT	SAVE POINTER
07E6	81	2C		INPUT6	CMP A	#',	IS IT A COMMA?
07E8	26	07			BNE	INPUT7	
07EA	08				INX		
07EB	96	12			LDA A	CRFLAG	TEST FLAG
07ED	27	AF			BEQ	INPUT1	
07EF	20	AA			BRA	INPUT0	
07F1	BD	03	08	INPUT7	JSR	TSTTRM	
07F4	26	13			BNE	INPUT9	
07F6	96	12		INPU72	LDA A	CRFLAG	TEST FLAG
07F8	27	03			BEQ	INPUT8	
07FA	7E	07	04	INPU75	JMP	RUNEXC	
07FD	BD	01	09	INPUT8	JSR	INCH	GET CHAR.
0800	81	0D			CMP A	#\$D	C.R.?
0802	26	F9			BNE	INPUT8	
0804	BD	02	EA		JSR	PCRLF	
0807	20	F1			BRA	INPU75	
0809	86	45		INPUT9	LDA A	#\$45	
080B	7E	04	61		JMP	MISTAK	REPORT ERROR

## \* GET AND PUT LABEL

080E	BD	05	7C	LABLES	JSR	FNDLBL	GO FIND IT
0811	BD	06	64	LABLS2	JSR	PUTLBL	GO PUT IT
0814	7E	03	6F		JMP	NXTSPC	GET TO NEXT SET

## \* DATA ROUTINE

0817	96	19		DATA	LDA A	RUNFLG	RUNNING?
0819	27	49			BEQ	READ6	
081B	BD	03	6F		JSR	NXTSPC	FIND NEXT
081E	97	1A			STA A	DATAFL	SET DATA FLAG
0820	DF	0C			STX	DATAST	SET POINTER

```

0822 DF 0E          STX    DATAPT
0824 20 3E          BRA    READ6      RETURN

```

\* READ DATA ROUTINE

```

0826 96 19      READ    LDA A  RUNFLG      RUNNING?
0828 27 3A          BEQ    READ6
082A 96 1A          LDA A  DATAFL      CHECK FLAG
082C 27 39          BEQ    READ8
082E BD 03 59      JSR    NXTBLK      GET NEXT
0831 BD 03 68      READ2 JSR    SKIPSP      GO CLASSIFY
0834 BD 05 7C          JSR    FNDLBL
0837 DF 33          STX    XTEMP4
0839 DE 04          LDX    BUFPNT
083B DF 35          STX    XTEMP5      SAVE IT
083D DE 0E          LDX    DATAPT      GET DATA PNTR
083F BD 0A 26      JSR    EXPR      GET DATA
0842 A6 00          LDA A  0,X      GET CHAR.
0844 BD 03 08      JSR    TSTTRM      TEST IT
0847 26 04          BNE    READ25
0849 DE 0C          LDX    DATAST      SET POINTER
084B 20 01          BRA    READ3
084D 08      READ25 INX      BUMP THE POINTER
084E DF 0E      READ3 STX    DATAPT
0850 DE 35          LDX    XTEMP5
0852 DF 04          STX    BUFPNT
0854 DE 33          LDX    XTEMP4
0856 8D B9          BSR    LABLS2
0858 81 2C          CMP A  #',      IS IT A COMMA?
085A 26 03          BNE    READ4
085C 08      INX
085D 20 D2          BRA    READ2      REPEAT
085F BD 03 08      READ4 JSR    TSTTRM
0862 26 03          BNE    READ8      ERROR
0864 7E 07 04      READ6 JMP    RUNEXC      RETURN
0867 86 51      READ8 LDA A  #$51
0869 7E 04 61      JMP    MISTAK

```

\* RESTORE DATA STRING

```

086C DF 22      RESTOR STX    XSAVE      SAVE POINTER
086E DE 0C          LDX    DATAST
0870 DF 0E          STX    DATAPT      FIX DATA PNTR
0872 DE 22          LDX    XSAVE      RESTORE POINTER
0874 20 EE          BRA    READ6

```

\* ON GOTO ROUTINE

```

0876 BD 03 59      ONGOTO JSR    NXTBLK      FIND NEXT BLOCK
0879 BD 0A 26          JSR    EXPR      EVAL. EXPR.
087C 96 64          LDA A  NUMBER+2
087E 84 0F          AND A  #$0F      MASK L.S. DIGIT
0880 36      PSH A      SAVE A
0881 7F 00 12      CLR    CRFLAG
0884 08      INX      BUMP THE POINTER
0885 08      INX
0886 A6 00          LDA A  0,X      GET CHAR
0888 81 54          CMP A  #'T      IS IT A "T"?
088A 27 02          BEQ    ONGOTO0
088C 97 12          STA A  CRFLAG      SET FLAG
088E BD 03 5B      ONGOTO0 JSR    NXTBL4      GET NEXT
0891 DF 22          STX    XSAVE      SAVE X
0893 32      PUL A      RESTORE A
0894 4A      ONGOT1 DEC A
0895 27 11          BEQ    ONGOT4
0897 E6 00      ONGOT2 LDA B  0,X      GET A CHAR,
0899 08      INX      BUMP THE POINTER
089A C1 2C          CMP B  #',      IS IT A COMMA?

```

```

089C 26 04          BNE      ONGOT3
089E DF 22          STX      XSAVE      SAVE THE POINTER
08A0 20 F2          BRA      ONGOT1      REPEAT
08A2 C1 0D          ONGOT3 CMP B   #$D      C^R^ ?
08A4 26 F1          BNE      ONGOT2
08A6 DE 22          LDX      XSAVE      RESTORE POINTER
08A8 D6 12          ONGOT4 LDA B   CRFLAG  CHECK FLAG
08AA 27 03          BEQ      ONGOT6
08AC 7E 09 32       JMP      GOSUB2
08AF 7E 07 84       ONGOT6 JMP      GOTO1

```

## \* ROUTINE

```

08B2 BD 03 6F       IF      JSR      NXTSPC      FIND NEXT
08B5 BD 0A 26       JSR      EXPR      EUAL EXPR
08B8 A6 00          LDA A   0,X      GET CHAR
08BA 8D 63          BSR      CLSREL      REL OPERATOR?
08BC 26 5C          BNE      IF9      ERROR!
08BE 36            PSH A      SAVE A
08BF A6 01          LDA A   1,X      GET CHAR
08C1 8D 5C          BSR      CLSREL      REL OP?
08C3 32            PUL A      RESTORE A
08C4 26 04          BNE      IF1
08C6 E6 01          LDA B   1,X
08C8 1B            ABA
08C9 08            INX
08CA 08            IF1      INX
08CB 36            PSH A      SAVE A
08CC BD 0A 26       JSR      EXPR      EVAL EXPR
08CF 32            PUL A
08D0 84 0F          AND A   #$0F      MASK
08D2 80 09          SUB A   #9      BIAS IT
08D4 2B 44          BMI      IF9      ERROR?
08D6 48            ASL A      TIMES FOUR
08D7 48            ASL A
08D8 B7 08 E2       STA A   OFFSET3+1
08DB BD 0B C4       JSR      SUB      GO COMPARE
08DE BD 0C BE       JSR      ZCHK      SET CC REG
08E1 20 FE          OFFSET3 BRA      *
08E3 2F 18          BRATBL BLE      IF4      BRANCH TABLE
08E5 20 30          BRA      IF8
08E7 26 14          BNE      IF4
08E9 20 2C          BRA      IF8
08EB 2C 10          BGE      IF4
08ED 20 28          BRA      IF8
08EF 2D 0C          BLT      IF4
08F1 20 24          BRA      IF8
08F3 27 08          BEQ      IF4
08F5 20 20          BRA      IF8
08F7 2E 04          BGT      IF4
08F9 20 1C          BRA      IF8
08FB 20 1D          BRA      IF9      ERROR!
08FD DE 04          IF4      LDX      BUFPNT  SET POINTER
08FF A6 00          LDA A   0,X      GET CHAR
0901 81 54          CMP A   #'T      IS IT A "T"?
0903 26 0F          BNE      IF6
0905 BD 03 6F       JSR      NXTSPC
0908 DF 04          STX      BUFPNT  SAVE POINTER
090A BD 0C E5       JSR      CLASS1  GO CLASSIFY
090D C1 03          CMP B   #3      IS IT A NUMBER?
090F 26 03          BNE      IF6
0911 7E 07 84       JMP      GOTO1  GO TO GOTO
0914 7E 07 30       IF6      JMP      RUNEX3
0917 7E 07 04       IF8      JMP      RUNEXC  GO PROCESS CMND
091A 86 62          IF9      LDA A   #$62  SET ERROR
091C 7E 04 61       JMP      MISTAK

```

## \* CLASSIFY RELATIONAL OPERATION

```

091F 81 3B      CLSREL  CMP A  #$3B
0921 23 06              BLS   CLSRE5
0923 81 3E              CMP A  #$3E      CHECK CHAR
0925 22 02              BHI   CLSRE5
0927 5F          CLR B          CLEAR FLAG
0928 39          RTS            RETURN
0929 5C          CLSRE5  INC B      SET FLAG
092A 39          RTS            RETURN

```

\* GOSUB ROUTINE

```

092B D6 19      GOSUB  LDA B  RUNFLG
092D 27 E8              BEQ   IF8
092F BD 03 6F      GOSUB2 JSR   NXTSPC      FIND NEXT
0932 7C 00 1B      GOSUB2 INC   SUBCNT
0935 BD 0A 26              JSR   EXPR        EVALUATE EXPR
0938 09              DEX
0939 BD 02 C6              JSR   FNDCRT      FIND C.R.
093C 08              INX          BUMP THE POINTER
093D A6 00              LDA A  0,X        GET LINE NO
093F 36              PSH A
0940 A6 01              LDA A  1,X
0942 36              PSH A          SAVE AS RET. ADD.
0943 9F 37              STS   CPX1        SAVE SP
0945 CE A0 23      LDX   #STKBOT+35
0948 BD 0C B1              JSR   CMPX        CHECK BOUNDS
094B 23 03              BLS   GOSUB4
094D 7E 02 A0      GOSUB4 JMP   ADJEN2      RPT OVFL
0950 7E 07 87      GOSUB4 JMP   GOTO2

```

\* RETURN ROUTINE

```

0953 86 73      RETURN  LDA A  #$73
0955 7A 00 1B              DEC   SUBCNT      DEC COUNTER
0958 2A 03              BPL   RETUR2
095A 7E 04 61              JMP   MISTAK      ERROR!
095D 32      RETUR2  PUL A          GET RET. ADD.
095E 33              PUL B
095F BD 02 A9              JSR   FINDLN      GO FIND LINE
0962 7E 07 8A              JMP   GOTO3

```

\* EXPRESSION EQUATE

```

0965 BD 05 7A      EXPEQU JSR   FNDLB0      FIND LABEL
0968 DF 33              STX   XTEMP4      SAVE
096A BD 03 6F              JSR   NXTSPC
096D 08              INX
096E BD 0A 26      EXPEQU JSR   EXPR        GO EVALUATE
0971 DE 33              LDX   XTEMP4      GET POINTER
0973 7E 06 64              JMP   PUTLBL      INSTALL

```

\* FOR ROUTINE

```

0976 BD 03 59      FOR    JSR   NXTBLK      FIND NEXT
0979 36              PSH A
097A 8D E9              BSR   EXPEQU
097C DE 08              LDX   DIMPNT
097E DF 37              STX   CPX1
0980 DE 06              LDX   FORSTK
0982 32              PUL A
0983 A7 00              STA A  0,X
0985 96 05              LDA A  BUFPNT+1
0987 09              DEX          DEC THE POINTER
0988 A7 00              STA A  0,X
098A 96 04              LDA A  BUFPNT      SET UP INDEX
098C 09              DEX
098D A7 00              STA A  0,X

```

098F	09			DEX		
0990	BD	0C	B1	JSR	CMPX	CHECK FOR OVFLW
0993	22	03		BHI	FOR5	
0995	7E	02	A0	JMP	ADJEN2	
0998	DF	06	FOR5	STX	FORSTK	SAVE POINTER
099A	7E	07	04	JMP	RUNEXC	

## \* NEXT ROUTINE

099D	BD	03	59	NEXT	JSR	NXTBLK	FIND NEXT
09A0	DF	1E			STX	NXPNTN	
09A2	DE	06			LDX	FORSTK	SET POINTER
09A4	BC	01	0F	NEXT1	CPX	MEMEND	OVFLW?
09A7	26	04			BNE	NEXT2	
09A9	DE	04			LDX	BUFPNT	RESTORE PNTR
09AB	20	74			BRA	NEXT9	ERROR!
09AD	08			NEXT2	INX		FIXUP POINTER
09AE	08				INX		
09AF	08				INX		
09B0	A1	00			CMP A	0,X	CHECK
09B2	26	F0			BNE	NEXT1	
09B4	09				DEX		FIX POINTER
09B5	09				DEX		
09B6	09				DEX		
09B7	DF	06			STX	FORSTK	
09B9	08				INX		
09BA	EE	00			LDX	0,X	
09BC	DF	04			STX	BUFPNT	SAVE IT
09BE	BD	05	7C		JSR	FNDLBL	FIND LABEL
09C1	DF	33			STX	XTEMP4	SAVE IT
09C3	BD	03	6F		JSR	NXTSPC	FIND NEXT
09C6	BD	0A	26		JSR	EXPR	EVALUATE
09C9	BD	0B	51		JSR	STAKUP	
09CC	DE	33			LDX	XTEMP4	RESTORE PNTR
09CE	BD	0B	44		JSR	GETVAL	GET LABEL VALUE
09D1	DE	04			LDX	BUFPNT	
09D3	A6	00			LDA A	0,X	GET CHAR
09D5	81	53			CMP A	#'S	IS IT STEP?
09D7	27	08			BEQ	NEXT4	
09D9	BD	03	0F		JSR	UPSCLR	
09DC	4C				INC A		
09DD	97	64			STA A	NUMBER+2	
09DF	20	0A			BRA	NEXT5	
09E1	BD	03	71	NEXT4	JSR	NXTSP4	
09E4	BD	0A	26		JSR	EXPR	
09E7	96	62			LDA A	NUMBER	
09E9	97	1C			STA A	LETFLG	SHOW NEG.
09EB	BD	0B	CA	NEXT5	JSR	ADD	GO ADD IN STEP
09EE	CE	00	10		LDX	#TRYVAL	SET POINTER
09F1	BD	06	64		JSR	PUTLBL	SAVE LABEL
09F4	BD	0B	C4		JSR	SUB	COMPARE
09F7	BD	0C	BE		JSR	ZCHK	SET CC REG
09FA	D6	1C			LDA B	LETFLG	CHK FLAG
09FC	2B	05			BMI	NEXT6	
09FE	06				TAP		SET CC
09FF	2C	12			BGE	NEXT8	
0A01	20	03			BRA	NEXT7	
0A03	06			NEXT6	TAP		SET CC
0A04	2F	0D			BLE	NEXT8	
0A06	DE	06		NEXT7	LDX	FORSTK	
0A08	08				INX		FIXUP PNTR
0A09	08				INX		
0A0A	08				INX		
0A0B	DF	06			STX	FORSTK	SAVE IT
0A0D	DE	1E			LDX	NXPNTN	
0A0F	DF	04			STX	BUFPNT	SAVE
0A11	20	0B			BRA	NEXT85	
0A13	CE	00	10	NEXT8	LDX	#TRYVAL	

```

0A16 BD 0B 44      JSR      GETVAL
0A19 DE 33      LDX      XTEMP4
0A1B BD 06 64      JSR      PUTLBL
0A1E 7E 07 04  NEXT85  JMP      RUNEXC
0A21 86 81      NEXT9  LDA  A  #$81      SET ERROR
0A23 7E 04 61  NEXT10  JMP      MISTAK

      * EXPRESSION HANDLER

0A26 7F 00 2C  EXPR    CLR      STKCNT      SET COUNT = 0
0A29 96 2C      EXPRO   LDA  A  STKCNT
0A2B 97 2D      STA  A  AUXCNT
0A2D 8D 04      BSR      EVAL
0A2F 4D      TST  A      CHECK FOR ERROR
0A30 26 F1      BNE      NEXTTIO
0A32 39      EXPR1    RTS      RETURN
      *
      **EVAL
      * EVALUATE AN ALGEBRAIC STRING
      *

0A33 9F FE      EVAL    STS      STKTOP      SAVE SP TOP
0A35 BD 0C DE  EVA0A   JSR      SKYCLS
0A38 DF 04      STX      BUFPT
0A3A C1 01      CMP  B  #1      SEE IF EMPTY EXPRESSION
0A3C 26 04      BNE      EVAL0
0A3E 86 21      LDA  A  #$21
0A40 20 4A      BRA      EVAL3
0A42 54      EVAL0    LSR  B      SET UP
0A43 C1 03      CMP  B  #3      CHECK FOR UNARY + OR -
0A45 26 03      BNE      EVAL1
0A47 BD 03 0F  JSR      UPSCLR
0A4A DE 04      EVAL1   LDX      BUFPT
0A4C BD 0C DE  EVAL1A  JSR      SKYCLS      GET NEXT CHAR
0A4F DF 04      STX      BUFPT
0A51 C1 04      CMP  B  #4      CHECK FOR OPERATORS
0A53 23 02      BLS      EVAL1Z
0A55 C6 05      LDA  B  #5      SET UP
0A57 58      EVAL1Z   ASL  B
0A58 F7 0A 5C  STA  B  OFFREL+1  SET UP BRANCH
0A5B 20 FE      OFFREL  BRA      *
0A5D 20 2B      BRA      EVAL2      ERROR
0A5F 20 1B      BRA      EVAL4      TERMINATOR
0A61 20 38      BRA      EVAL8      LETTER
0A63 20 2C      BRA      EVAL7      NUMBER
0A65 20 04      BRA      EVAL1C     RIGHT PAREN
0A67 36      PSH  A      SAVE
0A68 08      INX
0A69 20 CA      BRA      EVA0A      AGAIN
0A6B 30      EVAL1C   TSX      GET SP
0A6C 09      DEX      ADJUST
0A6D D6 18      LDA  B  DIMFLG
0A6F 9C FE      CPX      STKTOP      CHECK FOR EMPTY
0A71 27 06      BEQ      EVAL1E
0A73 32      PUL  A
0A74 5F      CLR  B
0A75 81 28      CMP  A  #'('      CHECK FOR L PAREN ON STACK
0A77 27 F2      BEQ      EVAL1C     IF SO, OK
0A79 5D      EVAL1E   TST  B      CHECK FOR ALRIGHT
0A7A 27 0E      BEQ      EVAL2      IF NOT SET, ERROR
0A7C 4F      EVAL4    CLR  A
0A7D D6 2C      LDA  B  STKCNT      GET STACK STKCNT
0A7F 5A      DEC  B      CHECK OP STACK
0A80 D1 2D      CMP  B  AUXCNT
0A82 26 06      BNE      EVAL2      IF NOT EMPTY, ERROR
0A84 30      TSX
0A85 09      DEX
0A86 9C FE      CPX      STKTOP      CHECK OPERATOR STACK
0A88 27 04      BEQ      EVAL3A     IF NOT EMPTY ERROR

```

0A8A	86	20	EVAL2	LDA A	#\$20	SET ERROR NUMBER
0A8C	9E	FE	EVAL3	LDS	STKTOP	GET SP
0A8E	DE	04	EVAL3A	LDX	BUFPNT	SET POINTER
0A90	39			RTS		
0A91	BD	0B 51	EVAL7	JSR	STAKUP	SHIFT OP STACK UP
0A94	DE	04		LDX	BUFPNT	
0A96	BD	03 1A		JSR	BCDCON	GET OPERAND
0A99	20	59		BRA	EVAL12	
0A9B	A6	01	EVAL8	LDA A	1,X	GET NEXT CHAR
0A9D	BD	0C E5		JSR	CLASS1	GO CLASSIFY
0AA0	C1	02		CMP B	#2	CHECK FOR LETTER
0AA2	26	28		BNE	EVAL9	IF NOT, VARIABLE
0AA4	A6	00		LDA A	0,X	GET CHAR BACK
0AA6	DF	22		STX	XSAVE	SET FOR ENTRY TO FIMDKY
0AA8	CE	01 7B		LDX	#FCTTBL	
0AAB	BD	03 85		JSR	FNDKE2	GO CHECK FUNCTION
0AAE	4D			TST A		CHECK SUCCESS
0AAF	27	CB		BEQ	EVAL4	
0AB1	7E	07 41		JMP	RUNEX4	GO SERVICE
0AB4	86	3F	EVAL86	LDA A	#'?	GET STGNUM OPERATOR
0AB6	36		EVAL87	PSH A		PUT ON STACK
0AB7	DE	22		LDX	XSAVE	
0AB9	7E	0A 35		JMP	EVA0A	
0ABC	86	40	EVAL85	LDA A	#'@	GET ABS OPERATOR
0ABE	20	F6		BRA	EVAL87	
0AC0	BD	03 0F	EVAL88	JSR	UPSCLR	MOVE STACK UP
0AC3	BD	0D 2A		JSR	RANDOM	COMPUTE RANDOM #
0AC6	97	64		STA A	NUMBER+2	
0AC8	DE	22	EVAL89	LDX	XSAVE	RESTORE POINTER
0ACA	20	28		BRA	EVAL12	
0ACC	D6	FE	EVAL9	LDA B	STKTOP	
0ACE	37			PSH B		
0ACF	D6	FF		LDA B	STKTOP+1	
0AD1	37			PSH B		
0AD2	D6	2D		LDA B	AUXCNT	GET COUNTER
0AD4	37			PSH B		SAVE
0AD5	D6	18		LDA B	DIMFLG	GET FLAG
0AD7	37			PSH B		SAVE
0AD8	BD	05 7A		JSR	FNDLB0	FIND VARIABLE STORAGE
0ADB	33			PUL B		GET FLAG
0ADC	D7	18		STA B	DIMFLG	RESTORE
0ADE	33			PUL B		GET COUNTER
0ADF	D7	2D		STA B	AUXCNT	RESTORE
0AE1	33			PUL B		
0AE2	D7	FF		STA B	STKTOP+1	
0AE4	33			PUL B		
0AE5	D7	FE		STA B	STKTOP	
0AE7	BD	0B 51		JSR	STAKUP	
0AEA	DE	20		LDX	XTEMP	
0AEC	BD	0B 44		JSR	GETVAL	MOVE VALUE TO NUMBER
0AEF	20	05		BRA	EVA12A	
0AF1	DE	04	EVA11C	LDX	BUFPNT	RESTORE POINTER
0AF3	08			INX		
0AF4	DF	04	EVAL12	STX	BUFPNT	SAVE POINTER
0AF6	30		EVA12A	TSX		
0AF7	09			DEX		
0AF8	9C	FE		CPX	STKTOP	CHECK OPERATOR STACK
0AFA	27	37		BEQ	EVAL10	IF EMPTY, DON'T OPERATE
0AFC	32			PUL A		
0AFD	36			PSH A		PUT BACK
0AFE	81	28		CMP A	#' (	CHECK FOR LEFT PAREM
0B00	27	31		BEQ	EVAL10	IF SO, DON'T OPERATE
0B02	BD	0C E5		JSR	CLASS1	GO CLASSIFY
0B05	37			PSH B		
0B06	54			LSR B		SET UP ID
0B07	96	2C		LDA A	STKCNT	GET COUNT
0B09	4A			DEC A		
0B0A	C1	04		CMP B	#4	CHECK FOR ABS OR SON



```

0B0C 27 04          BEQ      EVA12C    IF SO, GO AHEAD
0B0E 91 2D          CMP A  AUXCNT      OTHERWISE CHECK FOR 2 OPERANDS
0B10 27 21          BEQ      EVAL10    IF NOT, ABORT
0B12 81 09          EVA12C  CMP A  #9    CHECK OVERFLOW
0B14 23 04          BLS      EVA12D    OK
0B16 86 24          LDA A  #$24        SET ERROR
0B18 20 16          BRA      EVAL19
0B1A 32          EVA12D  PUL A          GET CLASSIFICATION
0B1B 33          PUL B          GET OPERATOR
0B1C 80 06          SUB A  #6          REMOVE BIAS
0B1E 48          ASL A          #2
0B1F B7 0B 26          STA A  OPOFF+1  SET UP JMP
0B22 CE 0B 36          LDX      #OPTBL  POINT
0B25 EE 00          OPOFF  LDX      0,X
0B27 AD 00          JSR      0,X        GO OPERATE
0B29 BD 0C BE          JSR      ZCHK     CHECK RESULT
0B2C 28 C8          BVC      EVA12A    IF NO OVFL, GO OPERATE AGAIN
0B2E 86 23          EVAL18  LDA A  #$23  SET ERROR NUMBER
0B30 7E 0A 8C          EVAL19  JMP      EVAL3
0B33 7E 0A 4A          EVAL10  JMP      EVAL1
0B36 0B CA          OPTBL  FDB      ADD
0B38 0B C4          FDB      SUB
0B3A 0C 82          FDB      SIGNUM
0B3C 0B BC          FDB      ABSVAL
0B3E 0B F4          FDB      MULT
0B40 0C 15          FDB      DIVIDE
0B42 0C 94          FDB      EXPON

*
** GET VALUE
* MOVE 3 BYTES POINTED TO BY X TO NUMBER
*
0B44 A6 00          GETVAL  LDA A  0,X      GET VALUE
0B46 97 62          STA A  NUMBER      STORE
0B48 A6 01          LDA A  1,X
0B4A 97 63          STA A  NUMBER+1
0B4C A6 02          LDA A  2,X
0B4E 97 64          STA A  NUMBER+2
0B50 39          RTS

*
*
** STACKUP
* ROLL OPERATIONAL STACK UPWARD
*
0B51 CE 00 3B          STAKUP  LDX      #STKEND  POINT TO END
0B54 E6 03          STAKU2  LDA B  3,X
0B56 E7 00          STA B  0,X        MOVE
0B58 08          INX
0B59 8C 00 62          CPX      #NUMBER      SEE IF DONE
0B5C 26 F6          BNE      STAKU2
0B5E 7C 00 2C          INC      STKCNT
0B61 39          RTS

*
*
** STACKDOWN
* ROLL OPERATIONAL STACK DOWNWARD
*
0B62 CE 00 64          STAKDN  LDX      #AX-1      POINT TO STORE
0B65 E6 00          STAKD1  LDA B  0,X
0B67 E7 03          STA B  3,X
0B69 09          DEX
0B6A 8C 00 3A          CPX      #STKEND-1  SEE IF DONE
0B6D 26 F6          BNE      STAKD1
0B6F 7A 00 2C          DEC      STKCNT
0B72 39          RTS

*
*
** UADD
* UNSIGNED ADD OF AX TO NUMBER

```

```

*
0B73 0C          UADD    CLC          ZERO THE CARRY
0B74 CE 00 64   UADD1    LDX      #NUMBER+2 POINT TO STORE
0B77 A6 00      UADD2    LDA A    0,X      GET ADDEND
0B79 A9 03              ADC A    3,X      ADD IN AUGEND
0B7B 19              DAA
0B7C A7 00              STA A    0,X      SAVE
0B7E 09              DEX
0B7F 8C 00 61      CPX      #NUMBER-1 SEE IF DONE
0B82 26 F3              BNE      UADD2
0B84 37          UADD22    PSH B
0B85 C6 02              LDA B    #$02      SET FOR OVFL
0B87 85 F0              BIT A    #$F0      AND AGAIN
0B89 26 01              BNE      UADD25
0B8B 5F              CLR B
0B8C DA 30          UADD25    ORA B    OVFLBF  RESET OFVL
0B8E D7 30              STA B    OVFLBF  SET OVFL IF NECESSARY
0B90 17              TBA
0B91 33              PUL B
0B92 39          UADD3    RTS
*
*
**USUB
* UNSIGNED SUBTRACT OF AX FROM NUMBER
*
0B93 8D 03      USUB      BSR      TENCOM      GO TEN'S COMPLEMENT
0B95 0D          SEC          FIX UP
0B96 20 DC          BRA      UADD1      GO ADD
*
*
**TENCOM
* UNSIGNED TEN'S COMPLEMENT OF AX (ALMOST)
*
0B98 CE 00 67   TENCOM    LDX      #AX+2      POINT TO AX
0B9B 86 99       TENCO1    LDA A    #$99
0B9D A0 00              SUB A    0,X      SUBTRACT FROM 99
0B9F A7 00              STA A    0,X      SAVE
0BA1 09              DEX
0BA2 8C 00 64      CPX      #AX-1
0BA5 26 F4              BNE      TENCO1
0BA7 84 0F          AND A    #$0F      RESET SIGN
0BA9 A7 01          STA A    1,X      STORE
0BAB 39              RTS
*
*
** SET SIN
* CALCULATE RESULT SIGN
*
0BAC 7F 00 30   SETSIN    CLR      OVFLBF      CLEAR OVFL INDICATOR
0BAF 96 65       SETSI0    LDA A    AX          GET SIGN
0BB1 16          TAB          SAVE
0BB2 C4 0F          AND B    #$0F      RESET SIGN
0BB4 D7 65          STA B    AX          PUT BACK
0BB6 97 2F          STA A    AXSIGN      SAVE SIGN
0BB8 98 62          EOR A    NUMBER      FORM NEW SIGN
0BBA 97 2E          STA A    SIGN        SAVE
0BBC D6 62          ABSVAL    LDA B    NUMBER      GET MS BYTE
0BBE C4 0F          AND B    #$0F      RESET SIGN
0BC0 D7 62          STA B    NUMBER      PUT BACK
0BC2 4D          TST A          TEST NEW SIGN
0BC3 39          RTS
*
*
**
* SUBTRACT AX FROM NUMBER
*
0BC4 96 62      SUB      LDA A    NUMBER      GET MS BYTE
0BC6 88 F0          EOR A    #$F0      CHANGE SIGN

```

```

0BC8 97 62          STA A  NUMBER      PUT BACK
                    * GO INTO ADD
                    *
                    *
                    * ADD
                    * ADD AX TO NUMBER
                    *
0BCA 8D 58          ADD      BSR      RELAY
0BCC 8D DE          BSR      SETSIN    GO CALCULATE SIGN
0BCE 2A 0A          BPL      ADD0      USE EITHER SIGN
0BD0 8D C1          BSR      USUB      OTHERWISE SUBTRACT
0BD2 06            TAP
0BD3 28 09          BVC      ADD1      CHECK OVERFLOW
0BD5 73 00 2F      COM      AXSIGN    CHANGE FOR AX SMALLER
0BD8 20 0B          BRA      ADD15
0BDA 8D 97          ADD0     BSR      UADD      GO ADD
0BDC 20 0A          BRA      ADD2      GO FIX SIGN
0BDE 8D 44          ADD1     BSR      RELAY    COPY NUMBER TO AX
0BE0 BD 03 0F      JSR      UPSCLR    RESTORE
0BE3 8D AE          BSR      USUB      GO NEGATE
0BE5 7F 00 30      ADD15     CLR      OVFLBF
0BE8 96 2F          ADD2     LDA A  AXSIGN    GET OLD SIGN
                    *
                    *
                    ** FIXSIN
                    * SET THE SIGN ON THE RESULT
                    *
0BEA 84 F0          FIXSIN   AND A  #$F0      MASK
0BEC C6 0F          LDA B  #$0F      SET MASK
0BEE D4 62          AND B  NUMBER    RESET SIGN
0BF0 1B            ABA          TACK ON SIGN
0BF1 97 62          STA A  NUMBER    PUT BACK
0BF3 39            FIX2     RTS
                    *
                    *
                    ** MULT
                    * MULTIPLY AC BY AX
                    *
0BF4 8D 2E          MULT     BSR      RELAY    MOVE STACK
0BF6 8D B4          BSR      SETSIN    GO CALC. SIGNS
0BF8 BD 03 0F      MULT0     JSR      UPSCLR    MOVE STACK UP
0BFB C6 05          LDA B  #5        SET COUNTER
0BFD 96 5F          MULT1     LDA A  AC      GET MS BYTE OF AC
0BFF 27 08          BEQ      MULT3    IF ZERO , LOOP
0C01 BD 0B 73      MULT2     JSR      UADD    ADD IN AX
0C04 7A 00 5F      DEC      AC      ONCE DONE
0C07 26 F8          BNE      MULT2
0C09 5A            MULT3     DEC B      ONCE DONE
0C0A 27 3D          BEQ      MULT4    CHECK IF ALL DONE
0C0C 8D 4A          BSR      ACLEFT   SHIFT AC LEFT
0C0E 96 62          LDA A  NUMBER
0C10 BD 0B 84      JSR      UADD22
0C13 20 E8          BRA      MULT1
                    *
                    *
                    ** DIVIDE
                    * DIVIDE AC-NUMBER BY AX
                    *
0C15 8D 0D          DIVIDE    BSR      RELAY
0C17 CE 00 65      LDX      #AX
0C1A BD 0C C1      JSR      ZCHK1    GO CHECK IF AX=0
0C1D 26 08          BNE      DIVID1   IF NOT, OK
0C1F 86 22          DIVID0    LDA A  #$22  SET ERROR
0C21 7E 0A 8C      JMP      EVAL3
0C24 7E 0B 62      RELAY     JMP      STAKDN  RELAY TO STACK DOWN
0C27 BD 0B AC      DIVID1     JSR      SETSIN  CALC, SIGNS
0C2A BD 0B 51      JSR      STAKUP    PUSH BACK
0C2D 8D 29          BSR      ACLEFT   SHIFT DOWN

```

```

0C2F 6F 02          CLR      2,X
0C31 6F 03          CLR      3,X      ZERO OUT NUMBER
0C33 C6 05          LDA B   #5      SET LOOP COUNT
0C35 8D 21          DIVID2 BSR   ACLEFT  MOVE AC DOWN
0C37 BD 0B 98      DIVI2A JSR   TENCOM  TAKE 10'S COMP
0C3A 8D 2E          DIVID3 BSR   DADD    GO SPECIAL ADD
0C3C 85 F0          BIT A   #$F0     CHECK FOR OVERFLOW
0C3E 26 13          BNE     DIVID4
0C40 BD 0B 98      JSR   TENCOM  IF SO, RESTORE AX
0C43 0C            CLC
0C44 8D 25          BSR   DADD1      ADD BACK IN
0C46 5A            DEC B   ONE PASS MADE
0C47 26 EC          BNE     DIVID2
0C49 96 2E          MULT4 LDA A   SIGN  GET THE SIGN
0C4B 8D 9D          BSR   FIXSIN  GO FIX UP THE SIGN
0C4D CE 00 5E      LDX   #AC-1  POINT TO AC
0C50 7E 0B 65      JMP   STAKD1  MOVE STACK BACK
0C53 7C 00 64      DIVID4 INC   NUMBER+2  ADD ONE IN
0C56 20 E2          BRA   DIVID3  GO DO AGAIN

*
*
** ACLEFT
* SHIFT AC-NUMBER LEFT 4 BITS
*
0C58 86 04          ACLEFT LDA A   #4      SET FOR 4 BITS
0C5A CE 00 64      ACLEF1 LDX   #AX-1  POINT X
0C5D 0C            CLC
0C5E 69 00          ACLEF2 ROL   0,X     ROTATE
0C60 09            DEX
0C61 8C 00 5E      CPX   #AC-1  CHECK IF DONE
0C64 26 F8          BNE     ACLEF2
0C66 4A            DEC A   CHECK FOR DONE
0C67 26 F1          BNE     ACLEF1
0C69 39            RTS

*
*
** DADD
* ADD AX TO A C
*
0C6A 0D            DADD   SEC
0C6B CE 00 61      DADD1 LDX   #AC+2
0C6E 96 5F          LDA A   AC      GET MS BYTE
0C70 84 0F          AND A   #$0F    RESET SIGN
0C72 97 5F          STA A   AC      STORE BACK
0C74 A6 00          DADD2 LDA A   0,X  GET ADDEND
0C76 A9 06          ADC A   6,X     ADD IN
0C78 19            DAA
0C79 A7 00          STA A   0,X     SAVE
0C7B 09            DEX
0C7C 8C 00 5E      CPX   #AC-1  SEE IF DONE
0C7F 26 F3          BNE     DADD2
0C81 39            RTS

*
** SIGNUM
* CALCULATE SIGNUM FUNCTION
*
0C82 8D 3A          SIGNUM BSR   ZCHK    GO CHECK = 0
0C84 27 0B          BEQ   SIGNU2  IF SOY RESULT =0
0C86 D6 62          LDA B   NUMBER  OTHERWISE GET SIGN
0C88 8D 07          SIGNU1 BSR   SIGNU2  GO CLEAR
0C8A 7C 00 64      INC   NUMBER+2  MAKE = I
0C8D 17            TBA      SET FOR FIXSIN
0C8E 7E 0B EA      JMP   FIXSIN  GO SET THE SIGN
0C91 7E 03 12      SIGNU2 JMP   CLRNUM

*
*
** EXPON
* CALCULATE EXPONENTIATION

```

```

* ONLY POSITIVE EXPONENTS UP TO 99 ALLOWED
*
0C94 8D 8E      EXPON   BSR      RELAY      MOVE OPERANDS DOWN
0C96 5F          CLR B
0C97 D7 30      STA B   OVFLBF      CLEAR OVER FLOW
0C99 96 67      LDA A   AX+2        GET EXPONENT
0C9B 27 EB          BEQ      SIGNU1    IF 0, GO MAKE RESULT +1
0C9D BD 0B 51    JSR      STAKUP      GET TWO COPIES
0CA0 8D 82          BSR      RELAY      MOVE DOWN
0CA2 8B 99      EXPON1  ADD A   #$99    DECREMENT
0CA4 19          DAA
0CA5 27 16      BEQ      CMPX2        WHEN 0 ALL DONE
0CA7 36          PSH A
0CA8 BD 0B AF    JSR      SETSI0      GO FIX SIGNS
0CAB BD 0B F8    JSR      MULT0       GO MULTIPLY
0CAE 32          PUL A
0CAF 20 F1      BRA      EXPON1      LOOP

*
*
** CMPX
* FULL COMPARE ON X
* COMPARES X WITH CONTENTS OF CPX1
*
0CB1 DF 39      CMPX     STX      CPX2      SAVE
0CB3 96 39      CMPX1    LDA A   CPX2      GET MS BYTE
0CB5 91 37          CMP A   CPX1      COMPARE
0CB7 26 04          BNE     CMPX2        IF NOT EQUAL, DONE
0CB9 D6 3A          LDA B   CPX2+1      GET LS BYTE
0CBB D1 38          CMP B   CPX1+1      COMPARE
0CBD 39          CMPX2    RTS          DOME

*
*
** ZCHK
* CHECK OPERAND FOR EQUAL TO 0
*
0CBE CE 00 62    ZCHK     LDX      #NUMBER
0CC1 5F          ZCHK1    CLR B
0CC2 6D 02          TST     2,X
0CC4 26 0E          BNE     ZCHK2
0CC6 6D 01          TST     1,X
0CC8 26 0A          BNE     ZCHK2
0CCA A6 00          LDA A   0,X        GET MS BYTE
0CCC 84 0F          AND A   #$0F
0CCE 26 04          BNE     ZCHK2        CHECK FOR 0
0CD0 A7 00          STA A   0,X        RESET SIGN BITS
0CD2 C6 04          LDA B   #4
0CD4 A6 00      ZCHK2    LDA A   0,X        GET MS BYTE
0CD6 46          ROR A
0CD7 84 08          AND A   #8        MOVE A SIGN BIT TO N
0CD9 1B          ABA          MASK N BIT
0CDA 9A 30          ORA A   OVFLBF      MERGE Z AND N
0CDC 06          TAP          ADD IN V
0CDD 39          RTS          SET CCR

*
*
**
0CDE BD 03 68    SKYCLS   JSR      SKIPSP
0CE1 20 02          BRA      CLASS1

*
*
**CLASS
*CLASSIFY A CHARACTER IN THE A ACCUMULATOR
*CLASSIFICATION RETURNED IN B
* 0 ERROR
* 1 TERMINATOR
* 2 LETTER
* 3 NUMBER
* 4 )

```

```

* 5 (
* 6 +
* 7 -
* 8 SGN
* 9 ABS
* 10 *
* 11 /
* 12 ~

0CE3 A6 00 CLASS LDA A 0,X GET CHAR
0CE5 C6 01 CLASS1 LDA B #1 SET UP
0CE7 81 0D CMP A #$D CHECK FOR CR
0CE9 27 17 BEQ CLAS25
0CEB 5A DEC B
0CEC 36 PSH A SAVE CHAR
0CED 80 28 CLAS2B SUB A #'( REMOVE BIAS
0CEF 2B 10 BMI CLASS2 CHECK ILLEGAL
0CF1 81 18 CMP A #'@-'( CHECK LIMIT
0CF3 23 0E BLS CLASS3 NOT LETTER
0CF5 81 32 CMP A #'Z-'( CHECK FOR LETTER
0CF7 23 06 BLS CLAS1B
0CF9 81 36 CMP A #'^-'( CHECK FOR ILLEGAL
0CFB 26 04 BNE CLASS2
0CFD C6 0A LDA B #10 FIX UP
0CFF CB 02 CLAS1B ADD B #02
0D01 32 CLASS2 PUL A RESTORE CHARACTER
0D02 39 CLAS25 RTS DONE
0D03 DF 24 CLASS3 STX XSAVE2 SAVE X REG
0D05 CE 0D 11 LDX #CLSTBL POINT TO TABLE
0D08 B7 0D 0C STA A CLSOFF+1 SET BIAS
0D0B E6 00 CLSOFF LDA B 0,X GET CLASSIFICATION
0D0D DE 24 LDX XSAVE2 RESTORE X REG,
0D0F 20 F0 BRA CLASS2
0D11 05 CLSTBL FCB 5,4,10,6,1,7,0,11,3,3,3,3
0D12 04 0A
0D14 06 01
0D16 07 00
0D18 0B 03
0D1A 03 03
0D1C 03
0D1D 03 FCB 3,3,3,3,3,3,1,1,1,1,1,8,9
0D1E 03 03
0D20 03 03
0D22 03 01
0D24 01 01
0D26 01 01
0D28 08 09

*
*
* RANDOM GENERATOR
*
0D2A C6 08 RANDOM LDA B #8 SET COUNTER
0D2C CE 00 00 LDX #RNDM
0D2F A6 03 RPT LDA A 3,X GET M.S. BYTE OF RANDOM NO.
0D31 48 ASL A SHIFT IT LEFT THREE:
0D32 48 ASL A TIMES TO GET BIT 28
0D33 48 ASL A IN LINE WITH BIT 31
0D34 A8 03 EOR A 3,X XOR A WITH RANDOM NO
0D36 48 ASL A PUT BIT 28.XOR31 IN
0D37 48 ASL A CARRY BY SHIFTING LEFT
0D38 69 00 ROL 0,X ROTATE ALL FOUR BYTES OF
0D3A 69 01 ROL 1,X THE RANDOM NO, ROTATING
0D3C 69 02 ROL 2,X THE CARRY INTO THE LSB
0D3E 69 03 ROL 3,X THE MSB IS LOST
0D40 5A DEC B DECREMENT THE COUNTER
0D41 26 EC BNE RPT IF ITS NOT 0, GO REPEAT
0D43 A6 00 LDA A 0,X PUT RANDOM # IN A
0D45 81 9F CMP A #$9F CHECK IN RANGE
0D47 22 E1 BHI RANDOM IN NOT GET ANOTHER

```

```

0D49 8B 00          ADD A  #0          SET HALF CARRY
0D4B 19             DAA
0D4C 39             RTS
0D4D             ENDSTR RMB 2
0D4F             STORSP EQU *
```

```

1F00             ORG      EXTERN
1F00 39           RTS
END
```

NO ERROR(S) DETECTED

SYMBOL TABLE:

ABSVAL	0BBC	AC	005F	ACLEF1	0C5A	ACLEF2	0C5E	ACLEFT	0C58
ADD	0BCA	ADD0	0BDA	ADD1	0BDE	ADD15	0BE5	ADD2	0BE8
ADDIN	0658	ADDIN1	065A	ADDIN2	0663	ADDX	05FA	ADJEN2	02A0
ADJEND	028A	ADSHF0	063B	ADSHF1	063F	AUXCNT	002D	AX	0065
AXSIGN	002F	BACKSP	0008	BCDC01	0330	BCDC01	0331	BCDC02	033D
BCDC04	0344	BCDCON	031A	BINCON	061E	BRATBL	08E3	BREAK	010C
BREAK2	045A	BUFFER	0068	BUFPNT	0004	CHRCNT	003E	CLAS1B	0CFF
CLAS25	0D02	CLAS2B	0CED	CLASS	0CE3	CLASS1	0CE5	CLASS2	0D01
CLASS3	0D03	CLEAR	019D	CLEAR2	019E	CLRBEG	018B	CLRBG2	0190
CLREND	0195	CLRNUM	0312	CLSOFF	0D0B	CLSRE5	0929	CLSREL	091F
CLSTBL	0D11	CMFX	0CB1	CMFX1	0CB3	CMFX2	0CBD	COLCON	0016
CONSKP	0364	COUNT	002B	CPX1	0037	CPX2	0039	CRFLAG	0012
CRLFST	0301	DADD	0C6A	DADD1	0C6B	DADD2	0C74	DATA	0817
DATAFL	001A	DATAPT	000E	DATAST	000C	DELCOD	0018	DIM	0671
DIM01	0687	DIM1	0694	DIM2	06AC	DIM5	06F0	DIM9	06A7
DIMFLG	0018	DIMN	0678	DIMPNT	0008	DIVI2A	0C37	DIVID0	0C1F
DIVID1	0C27	DIVID2	0C35	DIVID3	0C3A	DIVID4	0C53	DIVIDE	0C15
ENDSTR	0D4D	ERRSTR	0498	ERSTR2	04A1	EVA0A	0A35	EVA11C	0AF1
EVA12A	0AF6	EVA12C	0B12	EVA12D	0B1A	EVAL	0A33	EVAL0	0A42
EVAL1	0A4A	EVAL10	0B33	EVAL12	0AF4	EVAL18	0B2E	EVAL19	0B30
EVAL1A	0A4C	EVAL1C	0A6B	EVAL1E	0A79	EVAL1Z	0A57	EVAL2	0A8A
EVAL3	0A8C	EVAL3A	0A8E	EVAL4	0A7C	EVAL7	0A91	EVAL8	0A9B
EVAL85	0ABC	EVAL86	0AB4	EVAL87	0AB6	EVAL88	0AC0	EVAL89	0AC8
EVAL9	0ACC	EXPEQU	0965	EXPON	0C94	EXPON1	0CA2	EXPR	0A26
EXPR1	0A32	EXPRO	0A29	EXTERN	1F00	EXTRA	0029	EXTRNL	0701
FCTTBL	017B	FIELD1	04B1	FIELD2	04BA	FIELD3	04CC	FILB75	020E
FILBU2	01D8	FILBU6	01EB	FILBU7	0209	FILBU8	0213	FILBUF	01B0
FINDL1	02AC	FINDL2	02B1	FINDL4	02B3	FINDL6	02C1	FINDLN	02A9
FIX2	0BF3	FIXSIN	0BEA	FLDCNT	001D	FNDCRT	02C6	FNDKE2	0385
FNDKE4	0387	FNDKE5	039C	FNDKE6	039D	FNDKEY	037B	FNDL25	059C
FNDL45	05EC	FNDLB0	057A	FNDLB1	058E	FNDLB2	058F	FNDLB3	05B4
FNDLB4	05B6	FNDLB5	05F7	FNDLB9	060F	FNDLBL	057C	FNDLIN	02A5
FNDVAL	02C9	FNDVAR	0564	FOR	0976	FOR5	0998	FORSTK	0006
GETVAL	0B44	GOSUB	092B	GOSUB2	0932	GOSUB4	0950	GOTO	0781
GOTO1	0784	GOTO2	0787	GOTO3	078A	GOTO4	078F	GOTO5	0792
IF	08B2	IF1	08CA	IF4	08FD	IF6	0914	IF8	0917
IF9	091A	INCH	0109	INCHAR	02D0	INCHR2	02E2	INCHR4	02E9
INPU45	07CA	INPU72	07F6	INPU75	07FA	INPUT	0798	INPUT0	079B
INPUT1	079E	INPUT2	07AB	INPUT3	07B0	INPUT4	07BE	INPUT5	07DA
INPUT6	07E6	INPUT7	07F1	INPUT8	07FD	INPUT9	0809	INSERT	0264
INSERT3	026F	INSERT4	0275	INSERT6	0287	INSERT	0254	INTBRK	0452
KEYTBL	0111	LABLES	080E	LABLS2	0811	LBLTBL	00B0	LET	0772
LET2	077B	LETADR	0123	LETFLG	001C	LIST	03EC	LIST1	0409
LIST2	0414	LIST3	0418	LIST4	041B	LIST5	0428	LIST6	0433
LIST8	0441	MEMEND	010F	MICBAS	01A6	MISTA1	0465	MISTA2	0470
MISTA4	0478	MISTAK	0461	MONITR	E0E3	MONPC	A048	MULT	0BF4
MULT0	0BF8	MULT1	0BFD	MULT2	0C01	MULT3	0C09	MULT4	0C49
NEGFLG	0027	NEXT	099D	NEXT1	09A4	NEXT2	09AD	NEXT4	09E1
NEXT5	09EB	NEXT6	0A03	NEXT7	0A06	NEXT8	0A13	NEXT85	0A1E
NEXT9	0A21	NEXTIO	0A23	NOEXFL	0028	NUMBER	0062	NUMCNT	0026
NXPNTR	001E	NXTBL4	035B	NXTBLK	0359	NXTSP4	0371	NXTSPC	036F
OFFREL	0A5B	OFFSET	026B	OFSET2	024B	OFSET3	08E1	ONGOT0	088E
ONGOT1	0894	ONGOT2	0897	ONGOT3	08A2	ONGOT4	08A8	ONGOT6	08AF
ONGOTO	0876	OPOFF	0B25	OPSTAK	003F	OPTBL	0B36	OUTBC2	03C5

OUTBC3	03CD	OUTBC4	03D4	OUTBC6	03E0	OUTBC8	03E7	OUTBCD	03B1
OUTBCI	03B4	OUTCH	044C	OUTEEE	0106	OUTH1	0444	OUTHR	0448
OVFLBF	0030	PCRLF	02EA	PCRLF2	02FB	PDATA1	02EF	PFILBG	A002
PFILEN	A004	PIAADR	8004	PRIN45	04F2	PRIN47	04F8	PRIN51	0516
PRIN52	0522	PRIN55	0524	PRINT	04A6	PRINT0	04A9	PRINT1	04CF
PRINT2	04D8	PRINT4	04E5	PRINT5	0514	PRINT6	052E	PRINT7	0537
PRINT8	053C	PRINT9	0544	PRMPTC	0021	PSTRN4	055B	PSTRN8	055F
PSTRNG	0547	PUTLB2	0668	PUTLBL	0664	QMFLAG	0013	RANDOM	0D2A
READ	0826	READ2	0831	READ25	084D	READ3	084E	READ4	085F
READ6	0864	READ8	0867	RELAY	0C24	REPLA4	023C	REPLA5	0246
REPLA6	0252	REPLAC	0234	RESTOR	086C	RESTRT	0103	RETUR2	095D
RETURN	0953	RNDM	0000	ROWCON	0015	ROWVAR	0014	RPT	0D2F
RUN	075F	RUNE05	0716	RUNE22	0726	RUNE25	072B	RUNE27	072C
RUNE35	073E	RUNER1	047B	RUNER2	0483	RUNER4	0490	RUNEX0	0714
RUNEX1	071A	RUNEX2	0725	RUNEX3	0730	RUNEX4	0741	RUNEXA	0711
RUNEXC	0704	RUNFLG	0019	SETSI0	0BAF	SETSIN	0BAC	SIGN	002E
SIGNU1	0C88	SIGNU2	0C91	SIGNUM	0C82	SKIPS4	036E	SKIPSP	0368
SKPSP0	0367	SKYCLS	0CDE	STACK	A07F	STAKD1	0B65	STAKDN	0B62
STAKU2	0B54	STAKUP	0B51	START	0100	STKBOT	A000	STKCNT	002C
STKEND	003B	STKTOP	00FE	STORSP	0D4F	STUFLN	0223	SUB	0BC4
SUBCNT	001B	TABFLG	0017	TENCO1	0B9B	TENCOM	0B98	TIMTHR	0614
TRYVAL	0010	TSTLE1	0758	TSTLE2	075E	TSTLET	0745	TSTTR2	030E
TSTTRM	0308	UADD	0B73	UADD1	0B74	UADD2	0B77	UADD22	0B84
UADD25	0B8C	UADD3	0B92	UPSCLR	030F	USUB	0B93	XSAVE	0022
XSAVE2	0024	XTEMP	0020	XTEMP2	0031	XTEMP3	000A	XTEMP4	0033
XTEMP5	0035	ZCHK	0CBE	ZCHK1	0CC1	ZCHK2	0CD4		